





SM\_A7 DUCT(GA)\_R454B\_3D INV\_US1\_NA\_2402

# A7 DUCT 3D INVERTER SERIES

---

SERVICE MANUAL





---

## Table of Contents

---

### 1. Safety Precautions

1. Precautions
2. Information servicing

### 2. Model Reference & External Appearance

1. Model Reference
2. External Appearance

### 3. Indoor Unit

1. Feature
2. Dimensional Drawings
3. Part names
4. Service Place
5. Accessories
6. Fan Performance
7. Sound Pressure Levels
8. Refrigerant System Diagram
9. Electrical Characteristics
10. Electrical Wiring Diagrams

### 4. Installation

### 5. Product Features

### 6. Troubleshooting

1. Safety Caution
2. General Troubleshooting
3. Information Inquiry
4. Error Diagnosis and Troubleshooting Without Error Code
5. Quick Maintenance by Error Code
6. Troubleshooting by Error Code
7. Check Procedures

### Appendix

- i) Temperature Sensor Resistance Value Table for T1,T2,T3 and T4 (°C – K)
- ii) Temperature Sensor Resistance Value Table for TP (°C – K)
- iii) Pressure On Service Port



---

## Safety Precautions

## Contents

|  |   |
|--|---|
| 1. Precautions.....                                    | 2 |
| 2. Information servicing(For flammable materials)..... | 4 |

## 1. Precautions

To prevent personal injury, or property or unit damage, adhere to all precautionary measures and instructions outlined in this manual. Before servicing a unit, refer to this service manual and its relevant sections.

Failure to adhere to all precautionary measures listed in this section may result in personal injury, damage to the unit or to property, or in extreme cases, death.

 **WARNING** indicates a potentially hazardous situation which if not avoided could result in serious personal injury, or death.

 **CAUTION** indicates a potentially hazardous situation which if not avoided could result in minor or moderate personal injury, or unit damage.

### 1.1 In case of Accidents or Emergency

 **WARNING**

- If a gas leak is suspected, immediately turn off the gas and ventilate the area if a gas leak is suspected before turning the unit on.
- If strange sounds or smoke is detected from the unit, turn the breaker off and disconnect the power supply cable.
- If the unit comes into contact with liquid, contact an authorized service center.
- If liquid from the batteries makes contact with skin or clothing, immediately rinse or wash the area well with clean water.
- Do not insert hands or other objects into the air inlet or outlet while the unit is plugged in.
- Do not operate the unit with wet hands.
- Do not use a remote controller that has previously been exposed to battery damage or battery leakage.

 **CAUTION**

- Clean and ventilate the unit at regular intervals when operating it near a stove or near similar devices.
- Do not use the unit during severe weather conditions. If possible, remove the product from the window before such occurrences.

### 1.2 Pre-Installation and Installation

 **WARNING**

- Use this unit only on a dedicated circuit.
- Damage to the installation area could cause the unit to fall, potentially resulting in personal injury, property damage, or product failure.
- Only qualified personnel should disassemble, install, remove, or repair the unit.
- Only a qualified electrician should perform electrical work. For more information, contact your dealer, seller, or an authorized service center.

 **CAUTION**

- While unpacking be careful of sharp edges around the unit as well as the edges of the fins on the condenser and evaporator.

### 1.3 Operation and Maintenance

 **WARNING**

- Do not use defective or under-rated circuit breakers.
- Ensure the unit is properly grounded and that a dedicated circuit and breaker are installed.
- Do not modify or extend the power cable. Ensure the power cable is secure and not damaged during operation.
- Do not unplug the power supply plug during operation.
- Do not store or use flammable materials near the unit.
- Do not open the inlet grill of the unit during operation.
- Do not touch the electrostatic filter if the unit is equipped with one.
- Do not block the inlet or outlet of air flow to the unit.
- Do not use harsh detergents, solvents, or similar items to clean the unit. Use a soft cloth for cleaning.
- Do not touch the metal parts of the unit when removing the air filter as they are very sharp.
- Do not step on or place anything on the unit or outdoor units.
- Do not drink water drained from the unit
- Avoid direct skin contact with water drained from the unit.
- Use a firm stool or step ladder according to manufacturer procedures when cleaning or maintaining the unit.

 **CAUTION**

- Do not install or operate the unit for an extended period of time in areas of high humidity or in an environment directly exposing it to sea wind or salt spray.
- Do not install the unit on a defective or damaged installation stand, or in an unsecure location.
- Ensure the unit is installed at a level position
- Do not install the unit where noise or air discharge created by the outdoor unit will negatively impact the environment or nearby residences.
- Do not expose skin directly to the air discharged by the unit for prolonged periods of time.
- Ensure the unit do not operate in areas water or other liquids.
- Ensure the drain hose is installed correctly to ensure proper water drainage.
- When lifting or transporting the unit, it is recommended that two or more people are used for this task.
- When the unit is not to be used for an extended time, disconnect the power supply or turn off the breaker.



## WARNING For Using Flammable Refrigerant

### 1. Installation(where refrigerant pipes are allowed)

- Any person who is involved with working on or breaking into a refrigerant circuit should hold a current valid certificate from an industry-accredited assessment authority, which authorises their competence to handle refrigerants safely in accordance with an industry recognised assessment specification.
- Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
- That the installation of pipe-work shall be kept to a minimum.
- That pipe-work shall be protected from physical damage.
- Where refrigerant pipes shall be compliance with national gas regulations.
- That mechanical connections shall be accessible for maintenance purposes.
- Be more careful that foreign matter(oil, water,etc) does not enter the piping.

Also, when storing the piping, securely seal the opening by pinching, taping, etc.

- Appliance shall be stored in a well ventilated area where the room size corresponds to the room area as specified for operation.
- Appliance shall be stored in a well ventilated area where the room size corresponds to the room area as specified for operation.

- Joints shall be tested with detection equipment with a capability of 5 g/year of refrigerant or better, with the equipment in standstill and under operation or under a pressure of at least these standstill or operation conditions after installation. Detachable joints shall NOT be used in the indoor side of the unit(brazed, welded joint could be used).

- In cases that require mechanical ventilation, ventilation openings shall be kept clear of obstruction.

### 2. When a FLAMMABLE REFRIGERANT is used, the requirements for installation space of appliance and /or ventilation requirements are determined according to

- the mass charge amount(M) used in the appliance,
- the installation location,
- the type of ventilation of the location or of the appliance.
- piping material, pipe routing, and installation shall include protection from physical damage in operation and service, and be in compliance with national and local codes and standards, such as ASHRAE 15, IAPMO Uniform Mechanical Code, ICC International Mechanical Code, or CSA B52. All field joints shall be accessible for inspection prior to being covered or enclosed.
- that protection devices, piping, and fittings shall be protected as far as possible against adverse environmental effects, for example, the danger of water collecting and freezing in relief pipes or the accumulation of dirt and debris;
- that piping in refrigeration systems shall be so designed and installed to minimize the likelihood of hydraulic shock damaging the system;
- that steel pipes and components shall be protected against corrosion with a rustproof coating before applying any insulation;
- that precautions shall be taken to avoid excessive vibration or pulsation;
- the minimum floor area of the room shall be mentioned in the form of a table or a single figure without reference to a formula;
- after completion of field piping for split systems, the field pipe-work shall be pressure tested with an inert gas and then vacuum

tested prior to refrigerant charging, according to the following requirements:

- a. The minimum test pressure for the low side of the system shall be the low side design pressure and the minimum test pressure for the high side of the system shall be the high side design pressure, unless the high side of the system can not be isolated from the low side of the system in which case the entire system shall be pressure tested to the low side design pressure.
- b. The test pressure after removal of pressure source shall be maintained for at least 1 h with no decrease of pressure indicated by the test gauge, with test gauge resolution not exceeding 5% of the test pressure.
- c. During the evacuation test, after achieving a vacuum level specified in the manual or less, the refrigeration system shall be isolated from the vacuum pump and the pressure shall not rise above 1500 microns within 10 min. The vacuum pressure level shall be specified in the manual, and shall be the lesser of 500 microns or the value required for compliance with national and local codes and standards, which may vary between residential, commercial, and industrial buildings.

-- field-made refrigerant joints indoors shall be tightness tested according to the following requirements: The test method shall have a sensitivity of 5 grams per year of refrigerant or better under a pressure of at least 0,25 times the maximum allowable pressure. No leak shall be detected.

-- Any servicing shall be performed only as recommended by the manufacturer.

### 3. Qualification of workers

Any maintenance, service and repair operations must be required qualification of the working personnel. Every working procedure that affects safety means shall only be carried out by competent persons that joined the training and achieved competence should be documented by a certificate. The training of these procedures is carried out by national training organizations or manufacturers that are accredited to teach the relevant national competency standards that may be set in legislation. All training shall follow the ANNEX HH requirements of UL 60335-2-40 4th Edition.

Examples for such working procedures are:

- breaking into the refrigerating circuit;
- opening of sealed components;
- opening of ventilated enclosures.

## 2. Information servicing(For flammable materials)

### 2.1 Checks to the area

- Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimized. For repair to the refrigerating system, the following precautions shall be complied with prior to conducting work on the system.

### 2.2 Work procedure

- Work shall be undertaken under a controlled procedure so as to minimise the risk of a flammable gas or vapour being present while the work is being performed.

### 2.3 General work area

- All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided.

### 2.4 Checking for presence of refrigerant

- The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially flammable atmospheres.
- Ensure that the leak detection equipment being used is suitable for use with flammable refrigerants, i.e. no sparking, adequately sealed or intrinsically safe.

### 2.5 Presence of fire extinguisher

- If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO<sub>2</sub> fire extinguisher adjacent to the charging area.

### 2.6 No ignition sources

- No person carrying out work in relation to a REFRIGERATING SYSTEM which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks.
- "No Smoking" signs shall be displayed.

### 2.7 Ventilated area

- Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any

hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

### 2.8 Checks to the refrigeration equipment

- Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt consult the manufacturer's technical department for assistance. The following checks shall be applied to installations using FLAMMABLE REFRIGERANTS:
  - the actual refrigerant charge is in accordance with the room size within which the refrigerant containing parts are installed;
  - the ventilation machinery and outlets are operating adequately and are not obstructed;
  - if an indirect refrigerating circuit is being used, the secondary circuits shall be checked for the presence of refrigerant;
  - marking to the equipment continues to be visible and legible, marking and signs that are illegible shall be corrected;
  - refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.

### 2.9 Checks to electrical devices

- Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised.

#### Initial safety checks shall include:

- that capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
- that there no live electrical components and wiring are exposed while charging, recovering or purging the system;
- that there is continuity of earth bonding.

### 2.10 Sealed electrical components shall be replaced

### 2.11 Intrinsically safe components must be replaced

## 2.12 Cabling

- Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

## 2.13 Detection of flammable refrigerants

- Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.
- The following leak detection methods are deemed acceptable for refrigerant systems. Electronic leak detectors may be used to detect refrigerant leaks but, in the case of FLAMMABLE REFRIGERANTS, the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25 % maximum) is confirmed. Leak detection fluids are also suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.

NOTE Examples of leak detection fluids are

- bubble method,
- fluorescent method agents.
- If a leak is suspected, all naked flames shall be removed/ extinguished.
- If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak. See the following instructions of removal of refrigerant.

## 2.14 Removal and evacuation

- When breaking into the refrigerant circuit to make repairs or for any other purpose, conventional procedures shall be used. However, it is important that best practice is followed since flammability is a consideration.
- The following procedure shall be adhered to:
  - safely remove refrigerant following local and national regulations;
  - evacuate;
  - purge the circuit with inert gas(optional for A2L);
  - evacuate(optional for A2L);
  - continuously flush or purge with inert gas when using flame to open circuit; and open the circuit;
- The refrigerant charge shall be recovered into the correct recovery cylinders if venting is not allowed by local and

national codes. For appliances containing flammable refrigerants, the system shall be purged with oxygen-free nitrogen to render the appliance safe for flammable refrigerants. This process might need to be repeated several times. Compressed air or oxygen shall not be used for purging refrigerant systems.

- For appliances containing flammable refrigerants, refrigerants purging shall be achieved by breaking the vacuum in the system with oxygen-free nitrogen and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum (optional for A2L). This process shall be repeated until no refrigerant is within the system (optional for A2L). When the final oxygen-free nitrogen charge is used, the system shall be vented down to atmospheric pressure to enable work to take place.
- The outlet for the vacuum pump shall not be close to any potential ignition sources, and ventilation shall be available.

## 2.15 Charging procedures

- In addition to conventional charging procedures, the following requirements shall be followed:
  - Works shall be undertaken with appropriate tools only (In case of uncertainty, please consult the manufacturer of the tools for use with flammable refrigerants)
  - Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimize the amount of refrigerant contained in them.
  - Cylinders shall be kept upright.
  - Ensure that the refrigeration system is earthed prior to charging the system with refrigerant.
  - Label the system when charging is complete(if not already).
  - Extreme care shall be taken not to overfill the refrigeration system.
  - Prior to recharging the system it shall be pressure tested with OFN. The system shall be leak tested on completion of charging but prior to commissioning. A follow up leak test shall be carried out prior to leaving the site.

## 2.16 Decommissioning

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant. It is essential that electrical power is available before the task is commenced.

- Become familiar with the equipment and its operation.
- Isolate system electrically.
- Before attempting the procedure ensure that:
  - mechanical handling equipment is available, if required, for handling refrigerant cylinders;
  - all personal protective equipment is available and being

used correctly;

- the recovery process is supervised at all times by a competent person;
- recovery equipment and cylinders conform to the appropriate standards.
- Pump down refrigerant system, if possible.
- If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- Make sure that cylinder is situated on the scales before recovery takes place.
- Start the recovery machine and operate in accordance with manufacturer's instructions.
- Do not overfill cylinders. (No more than 80 % volume liquid charge).
- Do not exceed the maximum working pressure of the cylinder, even temporarily.
- When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.

## 2.17 Labelling

- Equipment shall be labelled stating that it has been decommissioned and emptied of refrigerant. The label shall be dated and signed. For appliances containing FLAMMABLE REFRIGERANTS, ensure that there are labels on the equipment stating the equipment contains FLAMMABLE REFRIGERANT.

## 2.18 Recovery

- When removing refrigerant from a system, either for servicing or decommissioning,
- it is recommended good practice that all refrigerants are removed safely.
- When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge is available. All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i. e. special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure-relief valve and associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.
- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of the flammable refrigerant. If in doubt the manufacturer should be consulted. In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect couplings and in good condition.

- The recovered refrigerant shall be processed according to local legislation in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.
- If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant. The compressor body shall not be heated by an open flame or other ignition sources to accelerate this process. When oil is drained from a system, it shall be carried out safely.

## 2.19 Transportation, marking and storage for units

1. Transport of equipment containing flammable refrigerants  
Compliance with the transport regulations
2. Marking of equipment using signs  
Compliance with local regulations
3. Disposal of equipment using flammable refrigerants  
Compliance with national regulations
4. Storage of equipment/appliances

The storage of equipment should be in accordance with the manufacturer's instructions.

5. Storage of packed (unsold) equipment

Storage package protection should be constructed such that mechanical damage to the equipment inside the package will not cause a leak of the refrigerant charge. The maximum number of pieces of equipment permitted to be stored together will be determined by local regulations.

---

# Model Reference

## Contents

|    |                                  |          |
|----|----------------------------------|----------|
| 1. | <b>Model Reference.....</b>      | <b>2</b> |
| 2  | <b>External Appearance .....</b> | <b>2</b> |

## 1. Model Reference

| Indoor Unit Model |                  | Capacity (Btu/h) | Power Supply            |
|-------------------|------------------|------------------|-------------------------|
| Duct              | MTJ-09HWFN10-M1  | 9k               | 1Phase, 208/230V~, 60Hz |
|                   | MTJM-12HWFN10-M1 | 12k              |                         |
|                   | MTJ-18HWFN10-M1  | 18k              |                         |
|                   | MTJ-24HWFN10-M1  | 24k              |                         |
|                   | MTJ-36HWFN10-M2  | 36k              |                         |
|                   | MTJ-48HWFN10-M2  | 48k              |                         |
|                   | MHJ-60HWFN10-M2  | 60k              |                         |

## 2. External Appearance

### 2.1 Indoor Unit

Duct



---

# Indoor Unit-Duct


## Contents

|     |                                  |    |
|-----|----------------------------------|----|
| 1.  | Feature.....                     | 2  |
| 2.  | Dimensional Drawings .....       | 4  |
| 3.  | Part names .....                 | 5  |
| 4.  | Service Place.....               | 6  |
| 5.  | Accessories .....                | 7  |
| 6.  | Fan Performance.....             | 8  |
| 7.  | Sound Pressure Levels .....      | 23 |
| 8.  | Refrigerant System Diagram ..... | 26 |
| 9.  | Electrical Characteristics.....  | 27 |
| 10. | Electrical Wiring Diagrams.....  | 27 |

## 1. Feature

### 1.1 Static Pressure Increase

The maximum MSP is increased to 160Pa, which is industry-leading. And the maximum HSP is 200Pa, which is comparable to our competitors.




### 1.2 Real-time Constant Air Volume

With Auto Airflow Match, A7 Duct can automatically match the airflow volume to different ducting design, resulting in installation convenience, comfortable experience and cost saving.

### 1.3 Two-ways of Installation

Two types of installation methods can be selected: ceiling concealed and floor concealed(optional)



The MSP duct machine does not need to replace the water tray, and the water pump is compatible with two installation methods.




Horizontal Installation

Vertical Installation

## 1.4 Optimization of Duct Design

By applying the new design of duct, the interior noise level has been reduced significantly. End users would not get irritable easily even staying indoor for a long time.



## 1.5 Upgrade of Fan Motor

- The design of integrated motor bracket, which is three parts integrated into one part, can improve installation stability, more friendly disassembly and assembly
- The volute spring buckle design improves installation stability and makes disassembly and assembly more friendly.


## 1.6 Upgrade of Electric Control

The area of the electric control box has been increased by 10%, and the driver board has been miniaturized, reducing the area by 40%. Larger maintenance space, and more convenient to replace the electronic control box.


## 1.7 Upgrade of Drain Pump

Service area of A7 Duct is 20% more than A6.

No need to cross the hole when replacing drain pump and temperature sensor.




## 2. Dimensional Drawings




| Model    | unit | Outline Dimension |      |      |      | Air Outlet Opening Size |      | Air Return Opening Size |      | Size Of Mounted Lug |      | Fresh Air In-take Opening Size |     |
|----------|------|-------------------|------|------|------|-------------------------|------|-------------------------|------|---------------------|------|--------------------------------|-----|
|          |      | A                 | B    | C    | D    | E                       | F    | G                       | H    | I                   | J    | K                              | L   |
| (KBtu/h) |      |                   |      |      |      |                         |      |                         |      |                     |      |                                |     |
| 9/12     | mm   | 700               | 245  | 750  | 795  | 527                     | 178  | 592                     | 212  | 740                 | 640  | 100                            | 126 |
|          | inch | 27.6              | 9.6  | 29.5 | 31.3 | 20.7                    | 7.0  | 23.3                    | 8.3  | 29.1                | 25.2 | 3.9                            | 5.0 |
| 18/24    | mm   | 1000              | 245  | 750  | 795  | 827                     | 178  | 892                     | 212  | 1040                | 640  | 100                            | 126 |
|          | inch | 39.4              | 9.6  | 29.5 | 31.3 | 32.6                    | 7.0  | 35.1                    | 8.3  | 40.9                | 25.2 | 3.9                            | 5.0 |
| 36/48    | mm   | 1200              | 300  | 750  | 795  | 1027                    | 233  | 1092                    | 267  | 1240                | 640  | 125                            | 160 |
|          | inch | 47.2              | 11.8 | 29.5 | 31.3 | 40.4                    | 9.2  | 43.0                    | 10.5 | 48.8                | 25.2 | 4.9                            | 6.3 |
| 60       | mm   | 1400              | 380  | 800  | 845  | 1223                    | 320  | 1272                    | 330  | 1440                | 668  | 125                            | 160 |
|          | inch | 55.1              | 14.9 | 31.5 | 33.3 | 48.1                    | 12.6 | 50.1                    | 13.0 | 56.7                | 26.3 | 4.9                            | 6.3 |

### 3. Part names





---

#### 4. Service Place



## 5. Accessories

The air conditioning system comes with the following accessories. Use all of the installation parts and accessories to install the air conditioner. Improper installation may result in water leakage, electrical shock and fire, or equipment failure.


| Name  | Shape   | Quantity |
|---|---|----------|
| Manual  |                    | 2-4      |
| Refrigenout in/out pipe protection cover  |                    | 2        |
| Copper nut  |                    | 2        |
| Wired remote controller(with packing)   |                    | 1        |
| Outlet pipe sheath  |                   | 1        |
| Outlet pipe clasp   |                    | 1        |
| Drain joint & Seal ring   |                   | 1        |
| Magnetic ring(Wrap the electric wires S1 & S2 ( P & Q & E ) around the magnetic ring twice)               | <br>S1&S2(P&Q&E) | 1        |
| Magnetic ring(Hitch on the connective cable between the indoor unit and outdoor unit after installation.) |                  | 1        |
| Display panel   |                 | 1        |
| Remote controlle(purchase separately)   |                 | 1        |
| Dry battery(purchase separately)  |                  | 2        |
| Remote controller holder(purchase separately)   |                  | 1        |


Optional accessories:

- There are two types of remote controls: wired and wireless.
- Select a remote controller based on customer preferences and requirements and install in an appropriate place.
- Refer to catalogues and technical literature for guidance on selecting a suitable remote controller.


## 6. Fan Performance

9k







### Constant air volume




12k







### Constant air volume




18k







### Constant air volume




24k







### Constant air volume




36k







### Constant air volume




48k







### Constant air volume




60k






---

## Constant air volume



## 7. Sound Pressure Levels

### 7.1 Sound pressure level




Notes:


- Sound measured at 1.5m/4.92ft away from the center of the unit.
- Data is valid at free field condition
- Data is valid at nominal operation condition
- Reference acoustic pressure OdB = 20µPa
- Sound level will vary depending on a range of factors such as the construction -(acoustic absorption coefficient) of particular room in which the equipment is installed.
- The operating conditions are assumed to be standard.

## 7.2 NC Curves


MTJ-09HWFN10-M1




MTJM-12HWFN10-M1




MTJ-18HWFN10-M1




MTJ-24HWFN10-M1




MTJ-36HWFN10-M2



MTJ-48HWFN10-M2




MHJ-60HWFN10-M2



---

## 8. Refrigerant System Diagram




## 9. Electrical Characteristics

| Indoor model             |                    | 9k~24k        | 36k | 48k~60k |
|--------------------------|--------------------|---------------|-----|---------|
| Power                    | Phase              | 1             |     |         |
|                          | Frequency And Volt | 208/230V,60Hz |     |         |
| Minimum Circuit Ampacity | A                  | 3             | 4   | 5       |
| Max Fuse                 | A                  | 15            | 15  | 15      |


## 10. Electrical Wiring Diagrams

| IDU Capacity (Btu/h) | IDU Wiring Diagram |
|----------------------|--------------------|
| 9k~24k               | 16023000014312     |
| 36k~60k              | 16023000014555     |


| Abbreviation    | Paraphrase                                |
|-----------------|---|
| Y/G             | Yellow-Green Conductor                    |
| PUMP            | PUMP                                      |
| TO CCM Comm.Bus | Central Controller                        |
| T1              | Indoor Room Temperature                   |
| T2              | Coil Temperature of Indoor Heat Exchanger |



Indoor unit wiring diagram:16023000014555





## 10.1 Some connectors introduce:



A. For new fresh motor terminal port (also for Anion generator) CN43:


1. Connect the fan motor to the port, no need care L/N of the motor;
2. The output voltage is the power supply;
3. The fresh motor can not excess 200W or 1A, follow the smaller one;
4. The new fresh motor will be worked when the indoor fan motor work ;when the indoor fan motor stops , the new fresh motor would be stopped;
5. When the unit enters force cooling mode or capacity testing mode , the fresh motor isn't work.






B For ALARM terminal port CN33

1. Provide the terminal port to connect ALARM, but no voltage of the terminal port, the power from the ALARM system (not from the unit)
2. Although design voltage can support higher voltage, but we strongly ask you connect the power less than 24V, current less than 0.5A
3. When the unit occurs the problem, the relay would be closed, then ALARM works






C. For remote control (ON-OFF) terminal port CN23 and short connector of J7

1. Remove the short connector of J7 when you use ON-OFF function;
2. When remote switch off (OPEN); the unit would be off;
3. When remote switch on (CLOSE); the unit would be on;
4. When close/open the remote switch, the unit would be responded the demand within 2 seconds;
5. When the remote switch on, you can use remote controller/ wire controller to select the mode what you want; when the remote switch off, the unit would not respond the demand from remote controller/wire controller.

when the remote switch off, but the remote controller/wire controller are on, CP code would be shown on the display board.

6. The voltage of the port is 12V DC, design Max. current is 5mA.



## 10.2 Micro-Switch Introduce:

| FOR COOLING&HEATING OR COOLING ONLY MODE<br>SETTING |                 |              |
|---|-----------------|--------------|
| SW1   | ON<br>1 2 3 4   | ON<br>1      |
| MODE  | COOLING&HEATING | COOLING ONLY |
| FACTORY SETTING                                     | ✓               |              |

A. Micro-switch SW1 is for selection of mode.

Range: COOLING&HEATING, COOLING ONLY.

| FOR MAIN-SLAVE SETTING |                  |           |           |           |
|------------------------|------------------|-----------|-----------|-----------|
| SW1                    | ON<br>1 2 3 4    | ON<br>3 4 | ON<br>3 4 | ON<br>3 4 |
| MODE                   | MAIN<br>NO SLAVE | MAIN      | MAIN      | SLAVE     |
| FACTORY<br>SETTING     | ✓                |           |           |           |


B. Micro-switch SW1 is for setting the master or slave unit when the unit is in twin connection.

Range: Master no slave (Normal 1 drive 1 connection), Master (2 positions without difference), Slave

| FOR ANTI-COLD WIND |               |           |           |                   |
|--------------------|---------------|-----------|-----------|-------------------|
| SW2                | ON<br>1 2 3 4 | ON<br>1 2 | ON<br>1 2 | ON<br>1 2         |
| TELO               | 24°C          | 15°C      | 8°C       | EEPROM<br>DEFAULT |
| FACTORY<br>SETTING | ✓             |           |           |                   |

C. Micro-switch SW2 is for selection of indoor fan stop temperature (TELO) when it is in anti-cold wind action in heating mode.

Range: 24°C, 15°C, 8°C, according to EEPROM setting (reserved for special customizing).



| FOR TEMP. COMPENSATION(HEATING) |     |     |     |                |  |
|---------------------------------|-----|-----|-----|----------------|--|
| SW2                             |     |     |     |                |  |
| CODE                            | 6°C | 2°C | 4°C | EEPROM DEFAULT |  |
| FACTORY SETTING                 | ✓   |     |     |                |  |

D. Micro-switch SW2 is for selection of temperature compensation in heating mode. This helps to reduce the real temperature difference between ceiling and floor so that the unit could run properly. If the height of installation is lower, smaller value could be chosen.

Range: 6°C, 2°C, 4°C, E function (reserved for special customizing)

| FOR SETTING AUTO-RESTART |              |                  |
|--------------------------|--------------|------------------|
| SW8                      |              |                  |
| MODE                     | AUTO-RESTART | NOT AUTO-RESTART |
| FACTORY SETTING          | ✓            |                  |

E. Micro-switch SW8 is for selection of auto-restart function.

Range: Active, inactive

| FOR SETTING NETADDRESS |      |       |       |       |  |
|------------------------|------|-------|-------|-------|--|
| S1+SW8                 |      |       |       |       |  |
| CODE                   | 0~F  | 0~F   | 0~F   | 0~F   |  |
| NETADDRESS             | 0~15 | 16~31 | 32~47 | 48~63 |  |
| FACTORY SETTING        | ✓    |       |       |       |  |

E. Micro-switch S1 and dial-switch SW8 are for address setting when you want to control this unit by a central controller.

Range: 00-63

| FOR SETTING POWER |      |      |       |        |     |        |        |        |        |
|-------------------|------|------|-------|--------|-----|--------|--------|--------|--------|
| ENC1              |      |      |       |        |     |        |        |        |        |
| CODE              | 0    | 1    | 2     | 3      | 5   | 8      | 9      | A      | B      |
| POWER             | AUTO | 5~7K | 8~10K | 11~14K | 18K | 24~28K | 29~33K | 36~38K | 39~47K |
| FACTORY SETTING   | ✓    |      |       |        |     |        |        |        |        |

ACCORDING TO RELATED MODEL.

F. Dial-switch ENC1: The indoor PCB is universal designed for whole series units from 5K to 60K. This ENC1 setting will tell the main program what size the unit is.

Range: AUTO, 5-7K,8-10K,.....,60K

NOTE: AUTO means the indoor unit is equipped with different outdoor units, which can automatically identify the capacity of the outdoor unit, model, mono or multi zone and match the indoor unit parameters.

Usually there is glue on it because the switch position cannot be changed at random unless you want to use this PCB as a spare part to use in another unit. Then you have to select the right position to match the size of the unit.

---

## Installation

# Contents

1. Location Selection
2. Indoor Unit Installation
3. Drainage Pipe Installation
4. Refrigerant Pipe Installation
5. Engineering of Insulation
6. Engineering of Electrical Wiring

## 1. Location selection

### 1.1 Unit location selection can refer to installation manual.

### 1.2 DO NOT install the unit in the following locations:


- Areas with oil drilling or fracking.
- Coastal areas with high salt content in the air.
- Areas with caustic gases in the air, such as near hot springs.
- Areas that experience power fluctuations, such as factories
- Enclosed spaces, such as cabinets.
- Kitchens that use natural gas
- Areas with strong electromagnetic waves.
- Areas that store flammable materials or gas.
- Rooms with high humidity, such as bathrooms or laundry rooms.
- If possible, DO NOT install the unit where it is exposed to direct sunlight.

## 2. Indoor Unit Installation


### 2.1 Installation place

The distance between the mounted indoor unit should meet the specifications illustrated in the following diagram.


#### 1) Ceiling-mounted



#### 2) Wall-mounted




#### 2.2 Service space for indoor unit



#### 2.3 Hang Indoor Unit

1. Please refer to the following diagrams to locate the four positioning screw bolt holes on the ceiling. Be sure to mark the places where you will drill ceiling hook holes.



| Capacity(KBtu/h) | Size of mounted lug( (mm/inch)) |          |
|------------------|---------------------------------|----------|
|                  | I                               | J        |
| 9/12             | 740/29.1                        | 640/25.2 |
| 18/24            | 1040/40.9                       | 640/25.2 |
| 36/48            | 1240/48.8                       | 640/25.2 |
| 60               | 1440/56.7                       | 668/26.3 |

2. Install and fit pipes and wires after you have finished installing the main body. When choosing where to start, determine the direction of the pipes to be drawn out.

Especially in cases where there is a ceiling involved, align the refrigerant pipes, drain pipes, and indoor and outdoor lines with their connection points before mounting the unit..

3. Install hanging screw bolts.

1) Cut off the roof beam.

2) Strengthen the point at which the cut was made. Consolidate the roof beam..


4. After you select an installation location, align the refrigerant pipes, drain pipes, as well as indoor and outdoor wires with their connection points before mounting the unit..

5. Drill 4 holes 10cm (4") deep at the ceiling hook positions in the internal ceiling. Be sure to hold the drill at a 90° angle to the ceiling.


6. Secure the bolt using the included washers and nuts.

7. Install the four suspension bolts.

8. Mount the indoor unit with at least two people to lift and secure it. Insert suspension bolts into the unit's hanging holes. Fasten them using the washers and nuts provided.



9. Mount the indoor unit onto the hanging screw bolts with a block. Position the indoor unit flat using a level indicator to prevent leaks.



Note: Confirm the minimum drain tilt is 1/100 or more.

## 2.4 Duct installation


1. Install the filter(optional) according to the size of the air inlet.

2. Install the canvas tie-in between the body and duct.


3. The air inlet and air outlet duct should be far enough apart enough to a avoid air passage short-circuit.

4. Connect the duct according to the following diagram.

Ceiling-mounted



Wall-mounted



NOTE:

1. The min. length of the duct should be more than 1m, and fix on the air inlet by screws (applicable to the unit that the air inlet filter is not fasten by screws).

2. The inlet of the air duct needs to be installed with a grille, which needs to be fixed to the air duct with screws.

3. Do not place the connecting duct weight on the indoor unit.

4. When connecting the duct, use an nonflammable canvas tie-in to prevent vibrating.


5. Insulation foam must be wrapped outside the duct to avoid condensate. An internal duct underlayer can be added to reduce noise, if the end-user requires.

6. When the machine is wall-mounted, the machine should be concealed mounting, and the air inlet and outlet should be grille, and the grille should be fixed firmly with screws.


## 2.5 Wall mounted installation

The unit supports wall mounted, if the unit is purchased with a pump and requires vertical mounting, please follow the steps below:


1. Remove the electrical control box cover, unplug the pump and water level switch terminals from the main control board.
2. Disassemble the pump components.



3. Remove the 4 screws, rotate the water pump components by 90° and fix them to the water pump mounting plate again.




4. Install the pump parts to the machine and connect the wiring set.






## 2.6 Filter installation


1. Take off ventilation panel and flange,



2. Change the mounting positions of the ventilation panel and air return flange.


3. When installing the filter mesh, fit it into the flange as illustrated in the following figure.





## 2.7 Fresh air duct installation

Dimension :



## 3. Connect drain hose

The drainpipe is used to drain water away from the unit. Improper installation may cause unit and property damage.

### ⚠ CAUTION

- Insulate all piping to prevent condensation, which could lead to water damage.
- If the drainpipe is bent or installed incorrectly, water may leak and cause a water-level switch malfunction.
- In HEAT mode, the outdoor unit will discharge water. Ensure that the drain hose is placed in an appropriate area to avoid water damage and slippage.

- DO NOT pull the drainpipe forcefully. This could disconnect it.




### NOTE ON PURCHASING PIPES


- Installation requires a polyethylene tube (exterior diameter = 1.46-1.54in/3.7-3.9cm, interior diameter = 1.26in/3.2cm), which can be obtained at your local hardware store or dealer.

### Indoor Drainpipe Installation

Install the drainpipe as illustrated in the following Figure.

1. Cover the drainpipe with heat insulation to prevent condensation and leakage.
2. Attach the mouth of the drain hose to the unit's outlet pipe. Sheath the mouth of the hose and clip it firmly with a pipe clasp.
3. These units operate with a negative pressure at the drain connections and a drain trap is required. The trap needs to be installed as close to the unit as possible. Make sure the top of the trap is below the connection to the drain pan to allow complete drainage of the pan.






#### NOTE ON DRAINPIPE INSTALLATION

- When using an extended drainpipe, tighten the indoor connection with an additional protection tube. This prevents it from pulling loose.
- The drainpipe should slope downward at a gradient of at least 1/100 to prevent water from flowing back into the air conditioner.
- To prevent the pipe from sagging, space hanging wires every 39-59in(1-1.5m)
- If the outlet of the drainpipe is higher than the body's pump joint, use a lift pipe for the indoor unit's exhaust outlet. The lift pipe must be installed no higher than 21.7in (55cm) from the ceiling board. The distance between the unit and the lift pipe must be less than 7.9in (20cm).

Incorrect installation could cause water to flow back into the unit and flood.

- To prevent air bubbles, keep the drain hose level or slightly tilted up (<3in/75mm).

#### Drainpipe installation for units with a pump



a Metal clamp (accessory)  
 b Drain hose (accessory)  
 c Rising drain piping (vinyl pipe of 0.98in(25mm) nominal diameter and 1.26in(32mm) outer diameter) (field supply)  
 d Hanging bars (field supply)

**NOTE: When connecting multiple drainpipes, install the pipes as illustrated.**

#### Units with a pump




#### To check for water leaks


The procedure differs depending on whether electrical wiring is already finished. When the electrical wiring is not finished yet, you need to temporarily connect the user interface and power supply to the unit.

#### When electrical wiring is not finished yet

1. Temporarily connect electrical wiring.
2. Remove the switch box cover (a).
3. Connect the single-phase power supply (50 Hz, 230 V) to connections No. 1 and No. 2 on the terminal block for power supply and earth.
4. Reattach the switch box cover (a).



5. Turn ON the power.
6. Start cooling operation (see "11. Test Operation").
7. Gradually pour approximately 1 l of water through the air discharge outlet, and check for leaks.



a Water inlet  
 b Portable pump  
 c Water inlet cover  
 d Bucket (adding water through water inlet)  
 e Drain outlet for maintenance  
 f Refrigerant pipes

8. Turn OFF the power.
9. Disconnect the electrical wiring.
10. Remove the control box cover.

---

11. Disconnect the power supply and earth.

12. Reattach the control box cover.

**When electrical wiring is finished already**

1. Start cooling operation.

2. Gradually pour approximately 1 l of water through the air discharge outlet, and check for leaks.

## 4. Refrigerant Pipe Installation

### 4.1 Recommended copper pipe thickness

| Pipe diameter<br>(inch(mm)) | Thickness(inch/mm) |
|-----------------------------|--------------------|
| Ø1/4 (Ø6.35)                | 0.024/0.6          |
| Ø3/8 (Ø9.52)                | 0.028/0.7          |
| Ø1/2 (Ø12.7)                | 0.03/0.75          |
| Ø5/8 (Ø15.9)                | 0.03/0.75          |
| Ø3/4 (Ø19)                  | 0.031/0.8          |
| Ø7/8 (Ø22)                  | 0.039/1            |

### 4.2 Maximum length and drop height

Ensure that the length of the refrigerant pipe, the number of bends, and the drop height between the indoor and outdoor units meets the requirements shown in the following table.

| Capacity (Btu/h) | Max. Length (ft/m) | Max. Elevation (ft/m) |
|------------------|--------------------|-----------------------|
| 9k/12k           | 82/25              | 49.2/15               |
| 18k              | 98.4/30            | 65.6/20               |
| 24k              | 164/50             | 82/25                 |
| 36k/48k/60k      | 246/75             | 98.4/30               |

Caution:


1. The capacity test is based on the standard length and the maximum permissive length is based on the system reliability.

2. Oil traps

-If oil flows back into the outdoor unit's compressor, this might cause liquid compression or deterioration of oil return. Oil traps in the rising gas piping can prevent this.

-An oil trap should be installed every 20ft(6m) of vertical suction line riser (<36k Btu/h unit).

-An oil trap should be installed every 32.8ft(10m) of vertical suction line riser ( $\geq$ 36k Btu/h unit).



### 4.3 The procedure of connecting pipes


1. Choose the pipe size according to the specification table.

2. Confirm the cross way of the pipes.

3. Measure the necessary pipe length.

4. Cut the selected pipe with pipe cutter

- Make the section flat and smooth.



5. Insulate the copper pipe

- Before test operation, the joint parts should not be heat insulated.

6. Flare the pipe

- Insert a flare nut into the pipe before flaring the pipe
- According to the following table to flare the pipe.


| Pipe diameter<br>(inch(mm)) | Flare dimension A<br>(inch/mm) |           | Flare shape |
|-----------------------------|--------------------------------|-----------|-------------|
|                             | Min                            | Max       |             |
| Ø1/4 (Ø6.35)                | 0.33/8.4                       | 0.34/8.7  |             |
| Ø3/8 (Ø9.52)                | 0.52/13.2                      | 0.53/13.5 |             |
| Ø1/2 (Ø12.7)                | 0.64/16.2                      | 0.65/16.5 |             |
| Ø5/8 (Ø15.9)                | 0.76/19.2                      | 0.78/19.7 |             |
| Ø3/4 (Ø19)                  | 0.91/23.2                      | 0.93/23.7 |             |
| Ø7/8 (Ø22)                  | 1.04/26.4                      | 1.06/26.9 |             |

#### NOTE: MINIMUM BEND RADIUS

Carefully bend the tubing in the middle according to the diagram below.

DO NOT bend the tubing more than 90° or more than 3 times.

Use appropriate tool



min-radius 10cm(3.9")

- After flared the pipe, the opening part must be seal by end cover or adhesive tape to avoid duct or exogenous impurity come into the pipe.

7. Drill holes if the pipes need to pass the wall.

8. According to the field condition to bend the pipes so that it can pass the wall smoothly.

9. Bind and wrap the wire together with the insulated pipe if necessary.

10. Set the wall conduit.

11. Set the supporter for the pipe.

12. Locate the pipe and fix it by supporter.

- For horizontal refrigerant pipe, the distance between supporters should not be exceed 1m.
- For vertical refrigerant pipe, the distance between supporters should not be exceed 1.5m.

13. Connect the pipe to indoor unit and outdoor unit by using two spanners.

- Be sure to use two spanners and proper torque to fasten the nut, too large torque will damage the bellmouthing, and too small torque may cause leakage. Refer the following table for different pipe connection.

| Pipe diameter<br>(inch(mm)) | Torque                | Sketch map |
|-----------------------------|-----------------------|------------|
|                             | N.m(lb.ft)            |            |
| Ø1/4 (Ø6.35)                | 18~20<br>(13.3~14.8)  |            |
| Ø3/8 (Ø9.52)                | 32~39<br>(23.6~28.8)  |            |
| Ø1/2 (Ø12.7)                | 49~59<br>(36.1~43.5)  |            |
| Ø5/8 (Ø15.9)                | 57~71<br>(42~52.4)    |            |
| Ø3/4 (Ø19)                  | 67~101<br>(49.4~74.5) |            |
| Ø7/8 (Ø22)                  | 85~110<br>(62.7~81.1) |            |

## 5 . Engineering of Insulation

### 5.1 Insulation of refrigerant pipe

#### 1. Operational procedure of refrigerant pipe insulation

Cut the suitable pipe → insulation (except joint section) → flare the pipe → piping layout and connection → vacuum drying → insulate the joint parts

#### 2. Purpose of refrigerant pipe insulation

- During operation, temperature of gas pipe and liquid pipe shall be over-heating or over-cooling extremely. Therefore, it is necessary to carry out insulation; otherwise it shall debase the performance of unit and burn compressor.
- Gas pipe temperature is very low during cooling. If insulation is not enough, it shall form dew and cause leakage.
- Temperature of gas pipe is very high (generally 50-100°C/122-212°F) during heating. Insulation work must be carried out to prevent hurt by carelessness touching.


#### 3. Insulation material selection for refrigerant pipe

- The burning performance should over 120°C/248°F
- According to the local law to choose insulation materials
- Recommended insulation casing thickness

| Humidity<80%RH | Humidity ≥80%RH |
|----------------|-----------------|
| 10mm/0.39in    | 15mm/0.59in     |

#### 4. Installation highlights of insulation construction

- Gas pipe and liquid pipe shall be insulated separately, if the gas pipe and liquid pipe were insulated together; it will decrease the performance of air conditioner.



- The insulation material at the joint pipe shall be 5~10cm/1.97~3.97in longer than the gap of the insulation material.
- The insulation material at the joint pipe shall be inserted into the gap of the insulation material.
- The insulation material at the joint pipe shall be banded to the gap pipe and liquid pipe tightly.
- The linking part should be use glue to paste together

- Be sure not bind the insulation material over-tight, it may extrude out the air in the material to cause bad insulation and cause easy aging of the material.

### 5.2 Insulation of drainage pipe

#### 1. Operational procedure of refrigerant pipe insulation

Select the suitable pipe → insulation (except joint section) → piping layout and connection → drainage test → insulate the joint parts

#### 2. Purpose of drainage pipe insulation

The temperature of condensate drainage water is very low. If insulation is not enough, it shall form dew and cause leakage to damage the house decoration.

#### 3. Insulation material selection for drainage pipe

- The insulation material should be flame retardant material, the flame retardancy of the material should be selected according to the local law.
- Thickness of insulation layer is usually above 10mm/0.39in.
- Use specific glue to paste the seam of insulation material, and then bind with adhesive tape. The width of tape shall not be less than 5cm/1.97in. Make sure it is firm and avoid dew.

#### 4. Installation and highlights of insulation construction

- The single pipe should be insulated before connecting to another pipe, the joint part should be insulated after the drainage test.
- There should be no insulation gap between the insulation material.

---

## 6. Engineering of Electrical Wring

### 1. Highlights of electrical wiring installation

- All field wiring construction should be finished by qualified electrician.
- Air conditioning equipment should be grounded according to the local electrical regulations.
- Current leakage protection switch should be installed.
- Do not connect the power wire to the terminal of signal wire.
- When power wire is parallel with signal wire, put wires to their own wire tube and remain at least 300mm/11.8in gap.
- According to table in indoor part named “the specification of the power” to choose the wiring, make sure the selected wiring not small than the date showing in the table.
- Select different colors for different wire according to relevant regulations.
- Do not use metal wire tube at the place with acid or alkali corrosion, adopt plastic wire tube to replace it.
- There must be not wire connect joint in the wire tube If joint is a must, set a connection box at the place.
- The wiring with different voltage should not be in one wire tube.
- Ensure that the color of the wires of outdoor and the terminal No. are same as those of indoor unit respectively.

Table: Minimum Cross-Sectional Area able of Power and Signal Cables

| Rated Current of Appliance (A) | AWG |
|--------------------------------|-----|
| ≤ 6                            | 18  |
| 6 - 10                         | 16  |
| 10 - 16                        | 14  |
| 16 - 25                        | 12  |
| 25 - 32                        | 10  |

# Product Features


## Contents

|           |  |           |
|-----------|--|-----------|
| <b>1.</b> | <b>Display Function .....</b>  | <b>2</b>  |
| <b>2</b>  | <b>Safety Features .....</b>   | <b>3</b>  |
| <b>3.</b> | <b>Basic Functions.....</b>  | <b>4</b>  |
| 3.1       | Table .....  | 4         |
| 3.2       | Abbreviation.....  | 5         |
| 3.3       | Fan Mode.....  | 5         |
| 3.4       | Cooling Mode .....   | 5         |
| 3.5       | Heating Mode(Heat Pump Units) .....                                    | 6         |
| 3.6       | Auto-mode.....   | 6         |
| 3.7       | Drying Mode .....  | 7         |
| 3.8       | Forced Operation Function .....  | 7         |
| 3.9       | Timer Function .....   | 7         |
| 3.10      | Sleep Function.....  | 7         |
| 3.11      | Auto-Restart Function.....   | 7         |
| 3.12      | 8°C Heating(Heat pump units).....                                      | 7         |
| 3.13      | Follow me .....  | 8         |
| <b>4.</b> | <b>Optional Functions .....</b>  | <b>9</b>  |
| <b>5.</b> | <b>Using the wire controller to set external static pressure .....</b> | <b>10</b> |
| <b>6.</b> | <b>Using the wire controller to set airflow rate.....</b>              | <b>10</b> |

---

## 1. Display Function

Duct Type



---

## 2. Safety Features

### Compressor three-minute delay at restart

Compressor functions are delayed for up to ten seconds upon the first startup of the unit, and are delayed for up to three minutes upon subsequent unit restarts.

### Automatic shutoff based on discharge temperature

If the compressor discharge temperature exceeds a certain level for nine seconds, the compressor ceases operation.

### Inverter module protection

The inverter module has an automatic shutoff mechanism based on the unit's current, voltage, and temperature. If automatic shutoff is initiated, the corresponding error code is displayed on the indoor unit and the unit ceases operation.

### Indoor fan delayed operation

- When the unit starts, the louver is automatically activated and the indoor fan will operate after a period of setting time or the louver is in place.
- If the unit is in heating mode, the indoor fan is regulated by the anti-cold wind function.

### Compressor preheating

Preheating is automatically activated when T4 sensor is lower than setting temperature.

### Sensor redundancy and automatic shutoff

- If one temperature sensor malfunctions, the air conditioner continues operation and displays the corresponding error code, allowing for emergency use.
- When more than one temperature sensor is malfunctioning, the air conditioner ceases operation.

---

### 3. Basic Functions

#### 3.1 Table

| Functions |        | Auto mode |        |        |
|-----------|--------|-----------|--------|--------|
| Cases     |        | Case 1    | Case 2 | Case 3 |
| Models    | 9k~55k |           | ✓      |        |

Note: The detailed description of case 1 or case 2 is shown in the following function sections(from 3.4 to 3.6).

## 3.2 Abbreviation

Unit element abbreviations

| Abbreviation | Element                          |
|--------------|----------------------------------|
| T1           | Indoor room temperature          |
| T2           | Coil temperature of evaporator   |
| T3           | Coil temperature of condenser    |
| T4           | Outdoor ambient temperature      |
| TP           | Compressor discharge temperature |
| Tsc          | Adjusted setting temperature     |
| CDIFTEMP     | Cooling shutdown temperature     |
| HDIFTEMP2    | Heating shutdown temperature     |

In this manual, such as CDIFTEMP, HDIFTEMP2...etc., they are well-setting parameter of EEPROM.

## 3.3 Fan Mode

When fan mode is activated:

- The outdoor fan and compressor are stopped.
- Temperature control is disabled and no temperature setting is displayed.
- The indoor fan speed can be set to 1%~100% and auto.
- The louver operations are identical to those in cooling mode.
- Auto fan: In fan-only mode, AC operates the same as auto fan in cooling mode with the temperature set at 24°C(75°F).


## 3.4 Cooling Mode

### 3.4.1 Indoor Fan Control

- 1) In cooling mode, the indoor fan operates continuously. The fan speed can be set to 1%-100%, or low, medium, high and auto.
- 2) Auto fan action in cooling mode:
  - Descent curve
    - When T1-Tsc is lower than to 3.5°C/6.3°F, fan speed reduces to 80%;
    - When T1-Tsc is lower than to 1°C/1.8°F, fan speed reduces to 60%;
    - When T1-Tsc is lower than to 0.5°C/0.9°F, fan speed reduces to 40%;
    - When T1-Tsc is lower than to 0°C/0°F, fan speed reduces to 20%;
    - When T1-Tsc is lower than to -0.5°C/-0.9°F, fan speed reduces to 1%;
  - Rise curve
    - When T1-Tsc is higher than or equal 0°C/0°F, fan speed increases to 20%;


- When T1-Tsc is higher than or equal 0.5°C/0.9°F, fan speed increases to 40%;
- When T1-Tsc is higher than or equal 1°C/1.8°F, fan speed increases to 60%;
- When T1-Tsc is higher than or equal 1.5°C/2.7°F, fan speed increases to 80%;
- When T1-Tsc is higher than or equal 4°C/7.2°F, fan speed increases to 100%.

### 3.4.2 Condenser Temperature Protection



When the condenser temperature exceeds a configured value, the compressor ceases operation.

### 3.4.5 Evaporator Temperature Protection




- Off: Compressor stops.
- Decrease: Decrease the running frequency to the lower level per 1 minute.
- Hold: Keep the current frequency.
- Resume: No limitation for frequency.

## 3.5 Heating Mode(Heat Pump Units)

### 3.5.1 Indoor Fan Control:

- 1) In heating mode, the indoor fan operates continuously. The fan speed can be set to 1%-100%, or low, medium, high and auto.
- Anti-cold air function

- If the temperature difference of T2 changes during auto fan and causes the fan speed to change, run the current fan speed for 30 seconds first, the default interval is the interval before the fan speed changes, and then judge T2 according to the current interval after 30 seconds to get the final anti-cold air interval.




$$\Delta TE1=0$$

## 2) Auto fan action in heating mode:

- Rise curve
  - When  $T1-Tsc$  is higher than  $-1.5^{\circ}C/-2.7^{\circ}F$ , fan speed reduces to 80%;
  - When  $T1-Tsc$  is higher than  $0^{\circ}C/0^{\circ}F$ , fan speed reduces to 60%;
  - When  $T1-Tsc$  is higher than  $0.5^{\circ}C/0.9^{\circ}F$ , fan speed reduces to 40%;
  - When  $T1-Tsc$  is higher than  $1^{\circ}C/1.8^{\circ}F$ , fan speed reduces to 20%.
- Descent curve
  - When  $T1-Tsc$  is lower than or equal to  $0.5^{\circ}C/0.9^{\circ}F$ , fan speed increases to 40%;
  - When  $T1-Tsc$  is lower than or equal to  $0^{\circ}C/0^{\circ}F$ , fan speed increases to 60%;
  - When  $T1-Tsc$  is lower than or equal to  $-1.5^{\circ}C/-2.7^{\circ}F$ , fan speed increases to 80%;
  - When  $T1-Tsc$  is lower than or equal to  $-3^{\circ}C/-5.4^{\circ}F$ , fan speed increases to 100%.

## 3.5.2 Evaporator Coil Temperature Protection



- Off: Compressor stops.
- Decrease: Decrease the running frequency to the lower level per 20 seconds.
- Hold: Keep the current frequency.
- Resume: No limitation for frequency.

## 3.6 Auto-mode

- This mode can be selected with the remote controller and the temperature setting can be adjusted between  $16^{\circ}C\sim30^{\circ}C$ .

### Case 1:

- In auto mode, the machine selects cooling, heating, or fan-only mode on the basis of  $\Delta T$  ( $\Delta T = T1-TS$ ).


| $\Delta T$   | Running mode |
|--|--------------|
| $\Delta T > 2^{\circ}C (3.6^{\circ}F)$                                     | Cooling      |
| $-3^{\circ}C (-5.4^{\circ}F) \leq \Delta T \leq 2^{\circ}C (3.6^{\circ}F)$ | Fan-only     |
| $\Delta T < -3^{\circ}C (-5.4^{\circ}F)$                                   | Heating*     |

Heating\*: In auto mode, cooling only models run the fan

- Indoor fan will run at auto fan speed.
- The louver operates same as in relevant mode.
- If the machine switches mode between heating and cooling, the compressor will keep stopping for certain time and then choose mode according to  $\Delta T$ .

### Case 2:


In auto mode, the machine selects cooling, heating or fan-only mode on the basis of  $T1, Ts$  and Outdoor ambient temperature( $T4$ ).



### Case 3:

In auto mode, the machine selects cooling, heating or

fan-only mode on the basis of  $T_1$ ,  $T_s$ , Outdoor ambient temperature( $T_4$ ) and relative humidity( $\phi$ ).




### 3.7 Drying mode

- In drying mode, AC operates the same as auto fan in cooling mode.
- All protections are activated and operate the same as they do that in cooling mode.
- Low Room Temperature Protection

If the room temperature is lower than  $10^{\circ}\text{C}/50^{\circ}\text{F}$ , the compressor ceases operations and does not resume until room temperature exceeds  $12^{\circ}\text{C}/53.6^{\circ}\text{F}$ .

### 3.8 Forced operation function

Press the AUTO/COOL button, the AC will run as below sequence:



- Forced cooling mode:

The compressor and outdoor fan continue to run and the indoor fan runs at breeze speed. After running for 30 minutes, the AC will switch to auto mode with a preset temperature of  $24^{\circ}\text{C}(76^{\circ}\text{F})$ .

- Forced auto mode:

Forced auto mode operates the same as normal auto mode with a preset temperature of  $24^{\circ}\text{C}(76^{\circ}\text{F})$ .

- The unit exits forced operation when it receives the following signals:

- Switch off
- Changes in:
  - mode
  - fan speed
  - sleep mode
  - Follow me

### 3.9 Timer Function

- The timing range is 24 hours.
- Timer On. The machine turns on automatically at the preset time.
- Timer Off. The machine turns off automatically at the preset time.
- Timer On/Off. The machine turns on automatically at the preset On Time, and then turns off automatically at the preset Off Time.
- Timer Off/On. The machine turns off automatically at the preset Off Time and then turns on automatically at the preset On Time.
- The timer does not change the unit operation mode. If the unit is off now, it does not start up immediately after the "timer off" function is set. When the setting time is reached, the timer LED switches off and the unit running mode remains unchanged.
- The timer uses relative time, not clock time

### 3.10 Sleep function

- The sleep function is available in cooling, heating, or auto mode.
- The operational process for sleep mode is as follows:
  - When cooling, the temperature rises  $1^{\circ}\text{C}/1.8^{\circ}\text{F}$  (to not higher than  $30^{\circ}\text{C}/86^{\circ}\text{F}$ ) every hour. After 2 hours, the temperature stops rising and the indoor fan is fixed at low speed.
  - When heating, the temperature decreases  $1^{\circ}\text{C}/1.8^{\circ}\text{F}$  (to not lower than  $16^{\circ}\text{C}/60.8^{\circ}\text{F}$ ) every hour. After 2 hours, the temperature stops decreasing and the indoor fan is fixed at low speed. Anti-cold wind function takes priority.
- The operating time for sleep mode is 8 hours, after which, the unit exits this mode.
- The timer setting is available in this mode.

### 3.11 Auto-Restart function

- The indoor unit has an auto-restart module that allows the unit to restart automatically. The module automatically stores the current settings and in the case of a sudden power failure, will restore those settings automatically within 3 minutes after power returns.

### 3.12 $8^{\circ}\text{C}$ Heating(Heat pump units)

In heating mode, the temperature can be set to as low as  $8^{\circ}\text{C}$ , preventing the indoor area from freezing if unoccupied during severe cold weather.

---

### 3.13 Follow me

- Once the follow me function is active, the remote control will send a signal every 3 minutes, with no beeps. The unit automatically sets the temperature according to the measurements from the remote control.
- The unit will only change modes if the information from the remote control makes it necessary, not from the unit's temperature setting.
- If the unit does not receive a signal for 7 minutes or you press "Follow Me," the function turns off. The unit regulates temperature based on its own sensor and settings.

## 4. Optional Functions

### 4.1 Silence(Multi-Zone Systems do not have this function)


- Press "Silence" or keep pressing Fan button for more than 2 seconds on the remote control to enable the SILENCE function. While this function is active, the compressor frequency is maintained at a lower level than F3. The indoor unit will run at faint breeze(1%), which reduces noise to the lowest possible level.
- When match with multi outdoor unit, this function is disabled.

### 4.2 ECO Function(Multi-Zone Systems do not have this function)

- Used to enter the energy efficient mode.
  - Under cooling mode, press ECO button, the remote controller will adjust the temperature automatically to 24°C/75°F, fan speed of Auto to save energy (but only if the set temperature is less than 24°C/75°F). If the set temperature is more than 24°C/75°F and 30°C/86°F, press the ECO button, the fan speed will change to Auto, the set temperature will remain unchanged.
  - When pressing the ECO button, or modifying the mode or adjusting the set temperature to less than 24°C/75°F, the AC will quit the ECO operation.
  - Operation time in ECO mode is 8 hours. After 8 hours the AC quits this mode.

### 4.3 Electrical energy consumption control function(Multi-Zone Systems do not have this function)

Press the "Gear" button on remote controller to enter the energy efficient mode in a sequence of following:



Turn off the unit or activate ECO, sleep, Super cool, 8°C Heating, Silence or self clean function will quit this function.

### 4.4 Active Clean function (Multi-Zone Systems do not have this function)


- The Active Clean Technology washes away dust, mold, and grease that may cause odors when it adheres to the heat exchanger by automatically freezing and then rapidly thawing the frost. The internal wind wheel then keeps operating to blow-dry the evaporator, thus preventing the growth of mold and keeping the inside clean.
- When this function is turned on, the indoor unit display window appears "CL", after 20 to 45 minutes, the unit will turn off automatically and cancel Active Clean function.

## 5. Using the wired controller to set external static pressure

- You can use the unit's automatic airflow adjustment function to set external static pressure.
- Automatic airflow adjustment is the volume of blow-off air that has been automatically adjusted to the quantity rated.

1. Make sure the test run is done with a dry coil. If the coil is not dry, run the unit for 2 hours in FAN ONLY mode to dry the coil.
2. Check that both power supply wiring and duct installation have been completed. Check that any closing dampers are open. Check that the air filter is properly attached to the air suction side passage of the unit.
3. If there is more than one air inlet and outlet, adjust the dampers so that the airflow rate of each air inlet and outlet conforms with the designed airflow rate. Make sure the unit is in FAN ONLY mode. Press and set the airflow adjustment button on the remote control to change the airflow rate from H or L.
4. Set the parameters for automatic airflow adjustment. When the air conditioning unit is off, perform the following steps:
  - When the unit is turned off, hold the MODE button and FAN button down together for three seconds. ("AF" indicator flashes for 3 times.)(for 12B wired controller) or long press COPY button for 3 seconds(for 120X/120G/120C/120M/120N wired controller).
  - Press "Δ" or "∇" to select the AF.
- F1 → F2 → F2b → F3 → F4 → SP → AF
- Press "MODE". The air conditioning unit will then start the fan for airflow automatic adjustment.

After 3 to 6 minutes, the air conditioning unit stops operating once automatic airflow adjustment has finished.



Caution: DO NOT adjust the dampers when automatic airflow adjustment is active.

Caution:

- If there is no change after airflow adjustment in the ventilation paths, be sure to reset automatic airflow adjustment.
- If there is no change to ventilation paths after airflow adjustment, contact your dealer, especially if this occurs after testing the outdoor unit or if the unit has been moved to a different location.
- Do not use automatic airflow adjustment with remote control, if you are using booster fans, outdoor air processing unit, or a HRV via duct.
- If the ventilation paths have been changed, reset airflow automatic adjustment as described from step 3 onwards.


For 120L/120K wired controller, perform the following steps:

- In power-on or standby mode, long press ON/OFF and FAN together for 7 seconds to engineer mode
- Press "Δ" or "∇" to select the channel "8".
- Press "On/Off" for 2s to enter the Static Pressure Selector, the code displayed is "Ch".
- Press "Δ" or "∇" to select the AF.
- Press "Confirm" to confirm.
- Press "On/Off" for 2s to exit.

## 6. Using the wired controller to set airflow rate

When the air conditioning unit is off, perform the following steps:

1. Press "MODE" and "FAN" for 3 seconds(for 12B wired controller) or long press COPY button for 3 seconds(for 120X/120G/120C/120M/120N wired controller).
2. Press "Δ" or "∇" to select the SP.
3. Press "MODE" to set the airflow rate in the range of 0~4.



"0": No airflow change

---

“1”~“4”:Airflow increase progressively

4. Press “ $\Delta$ ” or “ $\nabla$ ” to confirm airflow rate.(for 120 series wired remote controller, Press “confirm” to confirm airflow rate).
5. Press “ON/OFF” or do not touch the button for 6 minutes to exit the airflow setting.
6. Shut off the power supply and then turn it on.

For 120L/120K wired controller, perform the following steps:

- In power-on or standby mode, long press ON/OFF and FAN together for 7 seconds to engineer mode
- Press “ $\Delta$ ” or “ $\nabla$ ” to select the channel “8”.
- Press “On/Off” for 2s to enter the Static Pressure Selector, the code displayed is “Ch”.
- Press “ $\Delta$ ” or “ $\nabla$ ” to select the 0~8.
- Press “Confirm” to confirm.
- Press “On/Off” for 2s to exit.

# Troubleshooting

## Contents

|   |           |
|---|-----------|
| <b>1. Safety Caution .....</b>  | <b>3</b>  |
| <b>2. General Troubleshooting.....</b>  | <b>4</b>  |
| 2.1    Error Display (Indoor Unit) .....  | 4         |
| 2.2    Error Display on Two Way Communication Wired Controller .....  | 5         |
| <b>3. Engineering Mode .....</b>  | <b>6</b>  |
| 3.1    Information Inquiry .....  | 6         |
| 3.2    Advanced Function Setting .....  | 9         |
| <b>4. Error Diagnosis and Troubleshooting Without Error Code.....</b>   | <b>12</b> |
| 4.1    Remote maintenance .....   | 12        |
| 4.2    Field maintenance.....   | 13        |
| <b>5. Quick Maintenance by Error Code.....</b>  | <b>18</b> |
| <b>6. Troubleshooting by Error Code.....</b>  | <b>19</b> |
| 6.1    EH00/ EH0A / EC51 (EEPROM Malfunction Error Diagnosis and Solution) .....  | 19        |
| 6.2    EL01 (IDU & ODU communication error Diagnosis and Solution).....   | 20        |
| 6.3    EH03 / EC07 (Fan Speed Out of Control Diagnosis and Solution).....   | 23        |
| 6.4    EH60/EH61/EC53/EC52/EC54/EC56 (Open Circuit or Short Circuit of Temperature Sensor Diagnosis and Solution) ..... | 26        |
| 6.5    ELOC (System lacks refrigerant Diagnosis and Solution) .....   | 26        |
| 6.6    EH0E(Water-Level Alarm Malfunction Diagnosis and Solution).....  | 28        |
| 6.7    PC00(ODU IPM module protection Diagnosis and Solution).....  | 29        |
| 6.8    PC01(ODU voltage protection Diagnosis and Solution) .....  | 30        |
| 6.9    PC04(Inverter compressor drive error Diagnosis and Solution).....  | 31        |

---

# Troubleshooting

## Contents

|           |  |           |
|-----------|--|-----------|
| 6.10      | PC03(Pressure protection (low or high pressure) Diagnosis and Solution).....   | 32        |
| 6.11      | PC02(Compressor top (or IPM) temp. proteciton Diagnosis and Solution) .....  | 35        |
| 6.12      | PC0L (Low ambient temperature protection) .....  | 36        |
| 6.13      | EH b3 (Communication malfunction between wire and master control) Diagnosis and Solution<br>37   |           |
| 6.14      | EH bA(Communication error between the indoor unit and the external fan module)/<br>EH3A(External fan DC bus voltage is too low protection)/ EH3b(External fan DC bus voltage is too<br>high fault) diagnosis and solution..... | 38        |
| 6.15      | FHCC(Refrigerant sensor error) or EHC3(Refrigerant sensor is out of range) diagnosis and solution<br>39  |           |
| 6.16      | EHC1(Refrigerant sensor detects leakage) or EHC2(Refrigerant sensor is out of range and leakage<br>is detected) diagnosis and solution.....  | 40        |
| 6.17      | EL11 (Communication malfunction between main unit and secondary units(for twins system)<br>Diagnosis and Solution).....  | 41        |
| 6.18      | EH12 (Main unit or secondary units malfunction(for twins system) ) Diagnosis and Solution  | 41        |
| <b>7.</b> | <b>Check Procedures.....</b>   | <b>42</b> |

## 1. Safety Caution

### ⚠️ WARNING

Be sure to turn off all power supplies or disconnect all wires to avoid electric shock. While checking indoor/outdoor PCB, please equip oneself with antistatic gloves or wrist strap to avoid damage to the board.

### ⚠️ WARNING

Electricity remains in capacitors even when the power supply is off. Ensure the capacitors are fully discharged before troubleshooting.

**NOTE:** If using the inverter test tool maintenance, remove the big handle, take out the detection cable, take out female end of the cable and connect the inverter test tool. After the maintenance is completed, insert the female end back into the port.



Note: This picture is for reference only. Actual appearance may vary.

---

## 2. General Troubleshooting

### 2.1 Error Display (Indoor Unit)

When the indoor unit encounters a recognized error, the operation lamp will flash in a corresponding series, the timer lamp may turn on or begin flashing, and an error code will be displayed. These error codes are described in the following table:

| Display | Error Information   | Solution |
|---------|---|----------|
| FC      | Forced cooling(Not an error code)                                       | --       |
| EC01    | ODU fan speed out of control  | TS23     |
| EC01    | ODU EEPROM parameter error  | TS19     |
| EC02    | ODU coil temp. sensor(T3) error   | TS26     |
| EC03    | ODU ambient temp. sensor(T4) error                                      | TS26     |
| EC04    | COMP. discharge temp. sensor(TP) error                                  | TS26     |
| EC06    | IDU coil outlet temp. sensor(T2B) error(Multi-zone)                     | TS26     |
| EC01    | Other IDU refrigerant sensor detects leakage (Multi-zone)               | TS40     |
| EH00    | IDU EEPROM malfunction  | TS19     |
| EH03    | IDU fan speed out of control  | TS23     |
| EH08    | IDU EEPROM parameter error  | TS19     |
| EH0E    | Water-level alarm malfunction   | TS28     |
| EH12    | Main unit or secondary units malfunction                                | TS41     |
| EH3A    | External fan DC bus voltage is too low protection                       | TS38     |
| EH3b    | External fan DC bus voltage is too high fault                           | TS38     |
| EH60    | IDU room temp. sensor (T1) error  | TS26     |
| EH61    | IDU evaporator coil temp. sensor (T2) error                             | TS26     |
| EH8A    | Communication error between the indoor unit and the external fan module | TS38     |
| EH01    | Refrigerant sensor detects leakage                                      | TS40     |
| EH02    | Refrigerant sensor is out of range and leakage is detected              | TS40     |
| EH03    | Refrigerant sensor is out of range                                      | TS39     |

|      |   |      |
|------|---|------|
| EL01 | IDU & ODU communication error                                   | TS20 |
| EL02 | System lacks refrigerant  | TS27 |
| EL11 | Communication malfunction between main unit and secondary units | TS41 |
| FHCC | Refrigerant sensor error  | TS39 |
| PC00 | ODU IPM module protection                                       | TS29 |
| PC01 | ODU voltage protection  | TS30 |
| PC02 | Compressor top (or IPM) temp. protection                        | TS35 |
| PC03 | Pressure protection (low or high pressure) (for some models)    | TS32 |
| PC04 | Inverter compressor drive error                                 | TS31 |
| PC05 | Low ambient temperature protection(for some models)             | TS36 |
| ---- | IDUs mode conflict(Multi-zone)                                  | --   |

#### For other errors:

The display board may show a garbled code or a code undefined by the service manual. Ensure that this code is not a temperature reading.

#### Troubleshooting:

Test the unit using the remote control. If the unit does not respond to the remote, the indoor PCB requires replacement. If the unit responds, the display board requires replacement.

#### LED flash frequency:



## 2.2 Error Display on Two Way Communication Wired Controller

| Display | Malfunction or Protection   | Solution |
|---------|---|----------|
| EHb3    | Communication malfunction between wire and master control((for KJR-120X/KJR-120M/ KJR-120N series wired controller) | TS37     |

The other error codes displayed on the wire controller are same from those on the unit.

### 3. Engineering Mode

#### 3.1 Information Inquiry

In order to enter to the engineering mode, and check the data of the system (data checking mode), Please make the following steps:

- Make sure that the AC is on the standby status, or working normally in a non-locked conditions.
- Press "Power" + "Fan" buttons together for 7s until the remote controller screen shows "0", and also "Auto, Cool, Dry, Heat, Battery" icons will be displayed at the same time.
- Press "Up" or "Down" button to choose different channel number that you want to check (from 0-30) on the remote controller, and then the display will show the parameter value

| Channel | Code | Meaning                                | Remark   |
|---------|------|--|--|
| 0       |      | Error code                             | Refer to next list of error code Empty means no error                              |
| 1       | T1   | Room temperature                       | Actual data, °C  |
| 2       | T2   | Indoor coil temperature                | Actual data, °C  |
| 3       | T3   | Outdoor coil temperature               | Actual data, °C  |
| 4       | T4   | Ambient temperature                    | Actual data, °C  |
| 5       | TP   | Discharge temperature                  | Actual data, °C  |
| 6       | FT   | Targeted frequency                     | Actual data  |
| 7       | Fr   | Actual frequency                       | Actual data  |
| 8       | dL   | Running current                        | 3.2A=3   |
| 9       | Ac   | AC voltage                             |  |
| 10      | Sn   | Reserved                               |  |
| 11      | od   | Indoor operating mode                  | 0-Off;1-Cooling;2-Heating;3-Fan only; 4-Drying;5-Auto;7-defrosting;12-Active clean |
| 12      | Pr   | Outdoor fan speed                      | Actual data/8  |
| 13      | Lr   | EXV opening steps                      | Actual data/8  |
| 14      | Ir   | Indoor fan speed                       | Actual data/8  |
| 15      | Hu   | Humidity (if a sensor there)           | Actual data, %   |
| 16      | TT   | Set temperature including compensation | Actual data, °C  |
| 17      | nA   | Reserved                               |  |
| 18      | nA   | Reserved                               |  |
| 19      | Uo   | Outdoor DC bus voltage                 |  |
| 20      | oT   | Target Frequency calculated by indoor  | Without limitation   |
| 21~29   | nA   | Reserved                               |  |
| 30      | AP   | Actual static pressure                 |  |

Please note that:

- 1-The Channel number indicates a certain parameter value (Check the below table).
- 2-The indoor unit display will show the code for 2s, and then the parameter value.
- 3-In the engineering mode, the other keys or operations are invalid except for the following buttons "Power", "Up", "Down", and "Ok".
- 4-In order to exit from the engineering mode, press "Power" + "Fan" buttons together for 2s to quit Checking and back to the home screen.

---

5-The engineering mode will be exited if there is no valid input data for 60s.

Error code of engineer mode

| Display | Error Information  |
|---------|--|
| EH00    | IDU EEPROM malfunction   |
| EH01    | IDU EEPROM parameter error   |
| EL01    | IDU & ODU communication error  |
| EH02    | Communication error between indoor unit and external fan module        |
| EH30    | Parameters error of indoor external fan                                |
| EH35    | Phase failure of indoor external fan                                   |
| EH36    | Indoor external fan current sampling bias fault                        |
| EH37    | Indoor external fan zero speed failure                                 |
| EH38    | Indoor external fan stall failure                                      |
| EH39    | Out of step failure of indoor external fan                             |
| EH3A    | Low voltage protection of indoor external fan DC bus                   |
| EH3B    | Indoor external fan DC bus voltage is too high fault                   |
| EH3E    | Indoor external fan overcurrent fault                                  |
| EH3F    | Indoor external fan module protection/hardware overcurrent protection  |
| EH03    | IDU fan speed out of control   |
| ECS1    | ODU EEPROM parameter error   |
| ECS2    | ODU coil temp. sensor(T3) error  |
| ECS3    | ODU ambient temp. sensor(T4) error                                     |
| ECS4    | COMP. discharge temp. sensor(TP) error                                 |
| EC05    | IGBT temperature sensor TH is in open circuit or short circuit         |
| EC0d    | Outdoor unit malfunction   |
| EH60    | IDU room temp. sensor (T1) error                                       |
| EH61    | IDU evaporator coil temp. sensor (T2) error                            |
| EC01    | Outdoor external fan overcurrent fault                                 |
| EC05    | Outdoor external fan module protection/hardware overcurrent protection |
| EC02    | Outdoor external fan phase failure                                     |
| EC04    | Outdoor external fan current sampling bias fault                       |
| EC03    | Zero speed failure of outdoor unit DC fan                              |
| EC01    | ODU fan speed out of control   |
| EH05    | Intelligent eye communication failure                                  |
| EL02    | Refrigerant leak detected  |
| EH0E    | Water-level alarm malfunction  |
| EH0F    | Intelligent eye malfunction  |
| FH01    | Communication malfunction between indoor unit and auto-lifting panel   |
| PC00    | ODU IPM module protection  |
| PC01    | Over low voltage protection  |
| PC02    | Over voltage protection  |
| PC02    | DC voltage protection  |

---

|      |   |
|------|---|
| PC02 | Top temperature protection of compressor or High temperature protection of IPM module |
| PC40 | Communication error between outdoor main chip and compressor driven chip              |
| PC41 | Current Input detection protection  |
| PC42 | Compressor start error  |
| PC43 | Lack of phase (3 phase) protection  |
| PC44 | Outdoor unit zero speed protection  |
| PC45 | 341PWM error  |
| PC46 | Compressor speed malfunction  |
| PC49 | Compressor over current protection  |
| PC06 | Compressor discharge temperature protection   |
| PC08 | Outdoor current protection  |
| PH09 | Anti-cold air in heating mode   |
| PC0F | PFC module malfunction  |
| PC30 | System overpressure protection  |
| PC31 | System pressure is too low protection   |
| PC03 | Pressure protection   |
| PC0L | Outdoor low ambient temperature protection  |
| PH90 | Evaporator coil temperature over high protection                                      |
| PH91 | Evaporator coil temperature over low Protection                                       |
| PC0R | Condenser high temperature protection   |
| PH0C | Indoor unit humidity sensor failure   |
| LH00 | Frequency limit caused by T2  |
| LH30 | Indoor external fan current limit   |
| LH31 | Indoor external fan voltage limit   |
| LC01 | Frequency limit caused by T3  |
| LC02 | Frequency limit caused by TP  |
| LC05 | Frequency limit caused by voltage   |
| LC09 | Frequency limit caused by current   |
| LC06 | Frequency limit caused by PFC   |
| LC30 | Frequency limit caused by high pressure   |
| LC31 | Frequency limit caused by low pressure  |
| LC07 | Frequency limit caused by remote controller   |
| ---- | IDUs mode conflict(match with multi outdoor unit)                                     |
| NR   | No malfunction and protection   |

---

## 3.2 Advanced Function Setting

In order to enter to the engineering mode, and check the advanced function settings, Please make the following steps:

If you want to check the current functions set value (Presetting Page):

- 1- Firstly, you need to disconnect the power supply from the unit, and wait for 1 minute.
- 2- Then connect the power supply again to the unit (the unit should be under the standby state).
- 3- Press "Power" + "Fan" buttons together for 7s until the remote controller screen shows "0", and also "Auto, Cool, Dry, Heat, Battery" icons will be displayed at the same time.
- 4- Press "Up" or "Down" button to choose different channel number that you want to check (from 0-30) on the remote controller.
- 5- Then Press "Power" button for 2s until the remote controller screen shows "Ch" .
- 6- Press "OK" button to query the current function set value while the remote controller shows "CH", and the function set value will be shown on the indoor unit display.

If you want to change the current functions set value:

- 1- Firstly, you need to disconnect the power supply from the unit, and wait for 1 minute.
- 2- Then connect the power supply again to the unit (the unit should be under the standby state).
- 3- Press "Power" + "Fan" buttons together for 7s until the remote controller screen shows "0", and also "Auto, Cool, Dry, Heat, Battery" icons will be displayed at the same time.
- 4- Press "Up" or "Down" button to choose different channel number that you want to change (from 0-30) on the remote controller.
- 5- Then Press "Power" button for 2s until the remote controller screen shows "Ch".
- 6- Press "Up" or "Down" button to choose the desired set value from the screen of the remote control.
- 7- Then Press "OK" to send the new set value to the indoor unit, and the indoor unit will display "CS", which means that the new set value is uploaded successfully.
- 8- Finally, disconnect the power supply again from the unit, and wait for 10 minutes, then connect it again.

Please note that:

- 1- The Channel number indicates a certain function, and each number will be showed on the indoor unit screen indicates the current function set value (Check the below table).
- 2- In the engineering mode, the other keys or operations are invalid except for the following buttons "Power", "Up", "Down", and "Ok".
- 3- In order to set a new set value successfully, you need to finish the steps (from 2 to 7) within 1 minute only.
- 4- The engineering mode will be exited if there is no valid input data for 60s.
- 5- In order to exit from the engineering mode, Pleas follow the following steps:
  - Press "Power" button for 2s press until the remote controller screen shows "0".
  - Then Press "Power" + "Fan" buttons together for 2s to quit the engineering mode and back to the home screen.

| Channel | Function  | Parameter Value Meaning  | Remark                                 |
|---------|---|--|--|
| 0       | Capacity setting (Btu/h)                          | 1-100K   |  |
| 1       | Auto-restart function                             | 0 – Inactive<br>1 – Active   |  |
| 2       | Fan control when Ts reached                       | 1- Fan stop<br>2 - Fan runs at lowest RPM<br>3 - Fan runs at setting RPM<br>4~11 - Fan stops for 4 mins and runs for 1min  |  |
| 3       | Mode lock   | CH–Cooling and heating (all modes)<br>HH–Heating only (Heating + Fan only)<br>CC–Cooling only (Cooling + Drying + Fan only)<br>nU–Cooling and heating without Auto | Remote controller will change as well. |
| 4       | Lowest setting temperature                        | 16-24  | Remote controller will change as well. |
| 5       | Highest setting temperature                       | 25-30  | Remote controller will change as well. |
| 6       | Reserved  |  |  |
| 7       | Twins selection                                   | 0 – No twins; 1 – Master unit; 2 – Secondar unit   |  |
| 8       | Static pressure/ Constant air volume              | 0-8-Static pressure; AF-Constant air volume  |  |
| 9       | /   | Nothing to set   |  |
| 10      | /   | Nothing to set   |  |
| 11      | Min. frequency limitation in cooling mode         | 10, 11, 12, ..., 49, 50, -- (Cancel)   |  |
| 12      | Min. frequency limitation in heating mode         | 10, 11, 12, ..., 49, 50, -- (Cancel)   |  |
| 13      | Max frequency selection in T4 limitation of Zone6 | 20, 21, 22, ..., 149, 150, -- (Cancel)   |  |
| 14      | /   | Nothing to set   |  |
| 15      | Frequency selection of outdoor forced-operation   | 10, 11, 12, ..., 249, 250, -- (Cancel)   |  |
| 16      | One button reset                                  | rS – Reset   |  |
| 17      | nA  | Nothing to set   |  |
| 18      | Capacity setting(kW)                              | 23,26,32,35,51,72,120,-- (Cancel)  |  |
| 19      | Max. frequency selection in cooling mode          | 40, 41, 42, ..., 83, 84, -- (Cancel)   |  |
| 20      | Max. frequency selection in heating mode          | 40, 41, 42, ..., 83, 84, -- (Cancel)   | Without limitation                     |
| 21      | Cooling temperature compensation                  | -3.0, -2.5, -2.0, ..., 3.0, 3.5, -- (Cancel)   |  |

---

|    |                                     |  |  |
|----|-------------------------------------|--|--|
| 22 | Heating temperature compensation    | -6.5, -6.0, -5.5, ..., 0.5, 1.0, 1.5, ..., 7.0, 7.5, -- (Cancel) |  |
| 23 | Max. fan speed selection in cooling | -41, -40, -39, ..., 19, 20, -- (Cancel)                          |  |
| 24 | Min. fan speed selection in cooling | -41, -40, -39, ..., 19, 20, -- (Cancel)                          |  |
| 25 | Max. fan selection in heating       | -41, -40, -39, ..., 19, 20, -- (Cancel)                          |  |
| 26 | Min. fan speed selection in heating | -41, -40, -39, ..., 19, 20, -- (Cancel)                          |  |
| 27 | Reserved                            | Nothing to set   |  |
| 28 | Anti-cold air Stop Fan Temperature  | 16~28  |  |
| 29 | Reserved                            | Nothing to set   |  |
| 30 | Reserved                            | Nothing to set   |  |

## 4. Error Diagnosis and Troubleshooting Without Error Code

### **WARNING**

**Be sure to turn off unit before any maintenance to prevent damage or injury.**

### 4.1 Remote maintenance

**SUGGESTION:** When troubles occur, please check the following points with customers before field maintenance.

| No. | Problem  | Solution    |
|-----|--|-------------|
| 1   | Unit will not start                                      | TS14 - TS15 |
| 2   | The power switch is on but fans will not start           | TS14 - TS15 |
| 3   | The temperature on the display board cannot be set       | TS14 - TS15 |
| 4   | Unit is on but the wind is not cold(hot)                 | TS14 - TS15 |
| 5   | Unit runs, but shortly stops                             | TS14 - TS15 |
| 6   | The unit starts up and stops frequently                  | TS14 - TS15 |
| 7   | Unit runs continuously but insufficient cooling(heating) | TS14 - TS15 |
| 8   | Cool can not change to heat                              | TS14 - TS15 |
| 9   | Unit is noisy  | TS14 - TS15 |

---

## 4.2 Field maintenance

|    | Problem   | Solution    |
|----|---|-------------|
| 1  | Unit will not start                                   | TS16 - TS17 |
| 2  | Compressor will not start but fans run                | TS16 - TS17 |
| 3  | Compressor and condenser (outdoor) fan will not start | TS16 - TS17 |
| 4  | Evaporator (indoor) fan will not start                | TS16 - TS17 |
| 5  | Condenser (Outdoor) fan will not start                | TS16 - TS17 |
| 6  | Unit runs, but shortly stops                          | TS16 - TS17 |
| 7  | Compressor short-cycles due to overload               | TS16 - TS17 |
| 8  | High discharge pressure                               | TS16 - TS17 |
| 9  | Low discharge pressure                                | TS16 - TS17 |
| 10 | High suction pressure                                 | TS16 - TS17 |
| 11 | Low suction pressure                                  | TS16 - TS17 |
| 12 | Unit runs continuously but insufficient cooling       | TS16 - TS17 |
| 13 | Too cool  | TS16 - TS17 |
| 14 | Compressor is noisy                                   | TS16 - TS17 |
| 15 | Horizontal louver can not revolve                     | TS16 - TS17 |

| 1. Remote Maintenance                                    | Electrical Circuit                        | Refrigerant Circuit |
|--|---|---------------------|
| <b>Possible causes of trouble</b>                        |   |                     |
| Unit will not start                                      | ☆   | ☆                   |
| The power switch is on but fans will not start           | ☆   | ☆                   |
| The temperature on the display board cannot be set       |   | ☆                   |
| Unit is on but the wind is not cold(hot)                 |   | ☆                   |
| Unit runs, but shortly stops                             | ☆   |                     |
| The unit starts up and stops frequently                  | ☆   |                     |
| Unit runs continuously but insufficient cooling(heating) | ☆   | ☆                   |
| Cool can not change to heat                              |   | ☆                   |
| Unit is noisy  |   |                     |
| <b>Test method / remedy</b>                              |   |                     |
|  | Test voltage                              |                     |
|  | Close the power switch                    |                     |
|  | Inspect connections - tighten             |                     |
|  | Change the transformer                    |                     |
|  | Test voltage                              |                     |
|  | Replace the battery of the remote control |                     |
|  | Replace the remote control                |                     |
|  | Clean or replace                          |                     |
|  | Clean                                     |                     |
|  | Adjust the setting temperature            |                     |
|  | Turn the AC later                         |                     |
|  | Adjust to cool mode                       |                     |
|  | Turn off SILENCE function.                |                     |
|  | Turn the AC later                         |                     |

| 1. Remote Maintenance                                    | Others               |  |                                 |   |   |
|--|----------------------|--|---------------------------------|---|---|
| <b>Possible causes of trouble</b>                        | Heavy load condition | Loosen hold down bolts and / or screws | Bad airproof                    | The air inlet or outlet of either unit is blocked | Interference from cell phone towers and remote boosters   |
| Unit will not start                                      |                      |  |                                 |   |   |
| The power switch is on but fans will not start           |                      |  |                                 | ☆   |   |
| The temperature on the display board cannot be set       |                      |  |                                 |   |   |
| Unit is on but the wind is not cold(hot)                 |                      |  |                                 |   |   |
| Unit runs, but shortly stops                             |                      |  |                                 |   |   |
| The unit starts up and stops frequently                  |                      |  | ☆                               |   |   |
| Unit runs continuously but insufficient cooling(heating) | ☆                    | ☆                                      | ☆                               |   |   |
| Cool can not change to heat                              |                      |  |                                 |   |   |
| Unit is noisy  | ☆                    |  |                                 |   | ☆   |
| <b>Test method / remedy</b>                              | Check heat load      | Tighten bolts or screws                | Close all the windows and doors | Remove the obstacles                              | Reconnect the power or press <b>ON/OFF</b> button on remote control to restart operation<br>Remove them |

| 2. Field Maintenance  | Refrigerant Circuit |                  |   |                         |   |                        |   |                  |   |                       | Others |   |  |
|---|---------------------|------------------|---|-------------------------|---|------------------------|---|------------------|---|-----------------------|--------|---|--|
| <b>Possible causes of trouble</b>                                     |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Unit will not start   |                     | Compressor stuck |   | Shortage of refrigerant |   | Restricted liquid line |   | Dirty air filter |   | Dirty evaporator coil |        | Insufficient air through evaporator coil            |  |
| Compressor will not start but fans run                                | ☆                   |                  |   |                         |   |                        |   |                  |   |                       |        | Overcharge of refrigerant                           |  |
| Compressor and condenser (outdoor) fan will not start                 |                     |                  |   |                         |   |                        |   |                  |   |                       |        | Dirty or partially blocked condenser                |  |
| Evaporator (indoor) fan will not start                                |                     |                  |   |                         |   |                        |   |                  |   |                       |        | Air or incompressible gas in refrigerant cycle      |  |
| Condenser (Outdoor) fan will not start                                |                     |                  |   |                         |   |                        |   |                  |   |                       |        | Short cycling of condensing air                     |  |
| Unit runs, but shortly stops  |                     | ☆                | ☆ |                         |   |                        |   |                  |   |                       |        | High temperature condensing medium                  |  |
| Compressor short-cycles due to overload                               | ☆                   |                  |   |                         |   |                        |   |                  |   |                       |        | Insufficient condensing medium                      |  |
| High discharge pressure   |                     |                  |   |                         |   |                        |   | ☆                | ☆ |                       |        | Broken compressor internal parts                    |  |
| Low discharge pressure  |                     | ☆                |   |                         |   |                        |   |                  |   |                       |        | Inefficient compressor                              |  |
| High suction pressure   |                     |                  |   |                         |   |                        | ☆ |                  |   |                       |        | Expansion valve obstructed                          |  |
| Low suction pressure  | ☆                   | ☆                | ☆ | ☆                       | ☆ |                        |   |                  |   |                       |        | Expansion valve or capillary tube closed completely |  |
| Unit runs continuously but insufficient cooling                       | ☆                   | ☆                | ☆ | ☆                       | ☆ |                        | ☆ |                  |   |                       |        | Leaking power element on expansion valve            |  |
| Too cool  |                     |                  |   |                         |   |                        |   |                  |   |                       |        | Poor installation of feeler bulb                    |  |
| Compressor is noisy   |                     |                  |   |                         |   |                        | ☆ |                  |   |                       |        | Heavy load condition                                |  |
| Horizontal louver can not revolve                                     |                     |                  |   |                         |   |                        |   |                  |   |                       |        | Loosen hold down bolts and / or screws              |  |
| <b>Test method / remedy</b>   |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Replace the compressor  |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Leak test   |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Replace a restricted part   |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Clean or replace  |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Clean coil  |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Check fan   |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Change charged refrigerant volume                                     |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Clean condenser or remove obstacle                                    |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Purge, evacuate and recharge  |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Remove obstruction to air flow  |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Remove obstruction in air or water flow                               |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Remove obstruction in air or water flow                               |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Replace compressor  |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Test compressor efficiency  |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Replace valve   |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Replace valve   |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Replace valve   |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Fix feeler bulb   |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Check heat load   |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Tighten bolts or screws   |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Remove them   |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Choose AC of larger capacity or add the number of AC plate            |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |
| Rectify piping so as not to contact each other or with external plate |                     |                  |   |                         |   |                        |   |                  |   |                       |        |   |  |

| 2. Field Maintenance                                  |  | Electrical Circuit |                          |                               |                           |                                  |   |   |                             |                                    |  |                                   |                            |                                  |                                  |                               |
|---|--|--------------------|--------------------------|-------------------------------|---------------------------|----------------------------------|---|---|-----------------------------|------------------------------------|--|-----------------------------------|----------------------------|----------------------------------|----------------------------------|-------------------------------|
| Possible causes of trouble                            |  | Power failure      | Blown fuse or varistor   | Loose connections             | Shorted or broken wires   | Safety device opens              | Faulty thermostat / room temperature sensor   | Wrong setting place of temperature sensor | Faulty transformer          | Shorted or open capacitor          | Faulty magnetic contactor for compressor | Faulty magnetic contactor for fan | Low voltage                | Faulty stepping motor            | Shorted or grounded compressor   | Shorted or grounded fan motor |
| Unit will not start                                   |  | ☆                  | ☆                        | ☆                             | ☆                         | ☆                                |   |   | ☆                           |                                    |  |                                   |                            |                                  |                                  |                               |
| Compressor will not start but fans run                |  |                    |                          | ☆                             | ☆                         |                                  |   |   | ☆                           | ☆                                  |  |                                   |                            | ☆                                |                                  |                               |
| Compressor and condenser (outdoor) fan will not start |  |                    |                          | ☆                             | ☆                         |                                  |   |   |                             | ☆                                  |  |                                   |                            |                                  |                                  |                               |
| Evaporator (indoor) fan will not start                |  |                    |                          | ☆                             |                           |                                  |   |   | ☆                           |                                    | ☆  |                                   |                            |                                  | ☆                                |                               |
| Condenser (Outdoor) fan will not start                |  |                    |                          | ☆                             |                           | ☆                                |   |   | ☆                           |                                    | ☆  |                                   |                            |                                  | ☆                                |                               |
| Unit runs, but shortly stops                          |  |                    |                          |                               |                           |                                  |   |   |                             | ☆                                  |  |                                   | ☆                          |                                  | ☆                                |                               |
| Compressor short-cycles due to overload               |  |                    |                          |                               |                           |                                  |   |   |                             | ☆                                  |  |                                   | ☆                          |                                  |                                  |                               |
| High discharge pressure                               |  |                    |                          |                               |                           |                                  |   |   |                             |                                    |  |                                   |                            |                                  |                                  |                               |
| Low discharge pressure                                |  |                    |                          |                               |                           |                                  |   |   |                             |                                    |  |                                   |                            |                                  |                                  |                               |
| High suction pressure                                 |  |                    |                          |                               |                           |                                  |   |   |                             |                                    |  |                                   |                            |                                  |                                  |                               |
| Low suction pressure                                  |  |                    |                          |                               |                           |                                  |   |   |                             |                                    |  |                                   |                            |                                  |                                  |                               |
| Unit runs continuously but insufficient cooling       |  |                    |                          |                               |                           |                                  |   |   |                             |                                    |  |                                   |                            |                                  |                                  |                               |
| Too cool  |  |                    |                          |                               |                           |                                  |   |   | ☆                           | ☆                                  |  |                                   |                            |                                  |                                  |                               |
| Compressor is noisy                                   |  |                    |                          |                               |                           |                                  |   |   |                             |                                    |  |                                   |                            |                                  |                                  |                               |
| Horizontal louver can not revolve                     |  |                    |                          | ☆                             | ☆                         |                                  |   |   |                             |                                    |  |                                   |                            | ☆                                |                                  |                               |
| Test method / remedy                                  |  |                    |                          |                               |                           |                                  |   |   |                             |                                    |  |                                   |                            |                                  |                                  |                               |
|   |  | Test voltage       | Inspect fuse type & size | Inspect connections - tighten | Test circuits with tester | Test continuity of safety device | Test continuity of thermostat / sensor & wiring<br>Replace the temperature sensor at the central of the air inlet | Check control circuit with tester         | Check capacitor with tester | Test continuity of coil & contacts | Test continuity of coil & contacts       | Test voltage                      | Replace the stepping motor | Check resistance with multimeter | Check resistance with multimeter |                               |

## 5. Quick Maintenance by Error Code

If you do not have the time to test which specific parts are faulty, you can directly change the required parts according to the error code.

You can find the parts to replace by error code in the following table.

| Part requiring replacement | Error Code    |      |      |      |      |      |               |      |      |      |
|----------------------------|---------------|------|------|------|------|------|---------------|------|------|------|
|                            | EH00/<br>EH0R | EH01 | EH03 | EH05 | EH06 | EH0C | EH01/<br>EH02 | EH0E | EH03 | EH0b |
| Indoor PCB                 | ✓             | ✓    | ✓    | ✓    | ✓    | ✓    | ✗             | ✓    | ✗    | ✓    |
| Outdoor PCB                | ✗             | ✓    | ✗    | ✗    | ✗    | ✗    | ✗             | ✗    | ✓    | ✗    |
| Indoor fan motor           | ✗             | ✗    | ✓    | ✗    | ✗    | ✗    | ✗             | ✗    | ✗    | ✗    |
| T1 sensor                  | ✗             | ✗    | ✗    | ✓    | ✗    | ✗    | ✗             | ✗    | ✗    | ✗    |
| T2 sensor                  | ✗             | ✗    | ✗    | ✗    | ✓    | ✓    | ✗             | ✓    | ✗    | ✗    |
| T3 sensor                  | ✗             | ✗    | ✗    | ✗    | ✗    | ✗    | ✗             | ✗    | ✗    | ✗    |
| T4 sensor                  | ✗             | ✗    | ✗    | ✗    | ✗    | ✗    | ✗             | ✗    | ✓    | ✗    |
| Reactor                    | ✗             | ✓    | ✗    | ✗    | ✗    | ✗    | ✗             | ✗    | ✗    | ✗    |
| Compressor                 | ✗             | ✗    | ✗    | ✗    | ✗    | ✗    | ✗             | ✗    | ✗    | ✗    |
| Additional refrigerant     | ✗             | ✗    | ✗    | ✗    | ✗    | ✓    | ✓             | ✓    | ✗    | ✗    |
| Water-level switch         | ✗             | ✗    | ✗    | ✗    | ✗    | ✗    | ✗             | ✗    | ✓    | ✗    |
| Water pump                 | ✗             | ✗    | ✗    | ✗    | ✗    | ✗    | ✗             | ✗    | ✓    | ✗    |
| Display board              | ✗             | ✗    | ✗    | ✗    | ✗    | ✗    | ✗             | ✗    | ✗    | ✓    |

| Part requiring replacement | ECS4 | ECS1 | ECS2 | ECS6 | ECS1 | PC00 | PC01 | PC02 | PC04 | PC03 | EH0C/<br>EH03 |
|----------------------------|------|------|------|------|------|------|------|------|------|------|---------------|
| Indoor PCB                 | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✓             |
| Outdoor PCB                | ✓    | ✓    | ✓    | ✓    | ✓    | ✓    | ✓    | ✓    | ✓    | ✓    | ✗             |
| Outdoor fan motor          | ✗    | ✗    | ✗    | ✗    | ✓    | ✓    | ✗    | ✓    | ✓    | ✗    | ✗             |
| T3 sensor                  | ✗    | ✗    | ✓    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗             |
| TP sensor                  | ✓    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗             |
| T2B sensor                 | ✗    | ✗    | ✗    | ✓    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗             |
| Refrigerant sensor         | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✓             |
| Reactor sensor             | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✓    | ✗    | ✗    | ✗    | ✗             |
| Compressor                 | ✗    | ✗    | ✗    | ✗    | ✗    | ✓    | ✗    | ✗    | ✓    | ✗    | ✗             |
| IPM module board           | ✗    | ✗    | ✗    | ✗    | ✗    | ✓    | ✓    | ✓    | ✓    | ✗    | ✗             |
| Pressure protector         | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✓    | ✗             |
| Additional refrigerant     | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✗    | ✓    | ✗             |

## 6. Troubleshooting by Error Code


### 6.1 EH00/ EH0A / EC51 (EEPROM Malfunction Error Diagnosis and Solution)

**Description:** Indoor or outdoor PCB main chip does not receive feedback from EEPROM chip.

**Recommended parts to prepare:**

- Indoor PCB
- Outdoor PCB


**Troubleshooting and repair:**



**Remarks:**

**EEPROM:** A read-only memory whose contents can be erased and reprogrammed using a pulsed voltage.

The location of the EEPROM chip on the indoor and outdoor PCB is shown in the following two images:



This pictures are only for reference, actual appearance may vary.

Troubleshooting and repair of compressor driven chip EEPROM parameter error and communication error between outdoor main chip and compressor driven chip are same as EC51.

## 6.2 EL01 (IDU & ODU communication error Diagnosis and Solution)


**Description:** Indoor unit can not communicate with outdoor unit

**Recommended parts to prepare:**

- Indoor PCB
- Outdoor PCB
- Reactor


**Troubleshooting and repair:**

**Current loop Communication(S Communication):**




## Remarks:

- Use a multimeter to test the DC voltage between 2 port(or S or L2 port) and 3 port(or N or S port) of outdoor unit. The red pin of multimeter connects with 2 port(or S or L2 port) while the black pin is for 3 port(or N or S port) .
- When AC is operating normally, the voltage is moving alternately as positive values and negative values
- If the outdoor unit has malfunction, the voltage has always been the positive value.
- While if the indoor unit has malfunction, the voltage has always been a certain value.



- Use a multimeter to test the resistance of the reactor which does not connect with capacitor.
- The normal value should be around zero ohm. Otherwise, the reactor must have malfunction.



**Note: The picture and the value are only for reference, actual condition and specific value may vary.**


---

## 485 Communication(S1,S2 Communication):

### Recommended parts to prepare:

- Signal wires
- Magnet ring
- Indoor PCB
- Outdoor PCB

### Troubleshooting and repair:




## 6.3 EH03 / EC07 (Fan Speed Out of Control Diagnosis and Solution)

**Description:** When indoor / outdoor fan speed keeps too low or too high for a certain time, the unit ceases operation and the LED displays the failure.

### Recommended parts to prepare:

- Connection wires
- Fan assembly
- Fan motor
- PCB


### Troubleshooting and repair:



## Index:


### 1. Indoor DC Fan IPM Board

For A6 Duct Unit:



| Port | Description                 | Parameter | Remark              |
|------|-----------------------------|-----------|---------------------|
| CON1 | Power input for the PCB     | 230V/AC   |                     |
| CN1  | Communication with main PCB | DC        |                     |
| CN2  | Test port                   | 5V/DC     | For debugging board |
| CN23 | UVW output for DC fan motor |           |                     |
| CON2 | Ports for reactor           |           |                     |


#### CN1 Communication with main PCB



| NO. | Signal | Voltage |
|-----|--------|---------|
| 1   | Vcc    | +15V    |
| 2   | GND    |         |
| 3   | TXD    | 0~6V    |
| 4   | RXD    | 0~15V   |
| 5   | --     | --      |


For A7 Duct unit:

Power on and when the unit is in standby, measure the voltage of CN15, pin1-pin2 and pin3-pin2 of CN13 in DC motor driver board. If the value of the voltage is not in the range showing in below tables, the indoor main PCB must has problems and need to be replaced.



| Port  | Description                 | Parameter | Remark              |
|-------|-----------------------------|-----------|---------------------|
| CN15  | Power input for the PCB     | 230V/AC   | L, N and Earth      |
| CN13  | Communication with main PCB | DC        |                     |
| CN6   | Test port                   | 5V/DC     | For debugging board |
| CN20  | UVW output for DC fan motor |           |                     |
| CN18L | Ports for reactor           |           |                     |


#### CN13 Communication with main PCB



| NO. | Signal | Voltage |
|-----|--------|---------|
| 1   | Vcc    | +15V    |
| 2   | GND    |         |
| 3   | TXD    | 0~6V    |
| 4   | RXD    | 0~15V   |
| 5   | --     | --      |

#### 2. Outdoor DC Fan Motor (control chip is in outdoor PCB)

Release the UVW connector. Measure the resistance of U-V, U-W, V-W. If the resistance is not equal to each other, the fan motor must has problems and need to be replaced. otherwise the PCB must has problems and need to be replaced.





## 6.4 EH60/EH61/EC53/EC52/EC54/EC56 (Open Circuit or Short Circuit of Temperature Sensor Diagnosis and Solution)

**Description:** If the sampling voltage is lower than 0.06V or higher than 4.94V, the LED displays the failure.

**Recommended parts to prepare:**

- Connection wires
- Sensors
- PCB

**Troubleshooting and repair:**



This picture and the value are only for reference, actual appearance and value may vary


## 6.5 EL0C (System lacks refrigerant Diagnosis and Solution)

**Description:** Judging the abnormality of the refrigeration system according to the number of compressor stops and the changes in operating parameters caused by excessive exhaust temperature.

### Recommended parts to prepare:

- Indoor PCB
- Additional refrigerant

### Troubleshooting and repair:




## 6.6 EH0E(Water-Level Alarm Malfunction Diagnosis and Solution)

**Description:** If the sampling voltage is not 5V, the LED displays the failure code.

**Recommended parts to prepare:**

- Connection wires
- Water-level switch
- Water pump
- Indoor PCB




## 6.7 PC00(ODU IPM module protection Diagnosis and Solution)

**Description:** When the voltage signal the IPM sends to the compressor drive chip is abnormal, the display LED shows "PC00" and the AC turn off.

### Recommended parts to prepare:

- Connection wires
- IPM module board
- Outdoor fan assembly
- Compressor
- Outdoor PCB

### Troubleshooting and repair:




## 6.8 PC01(ODU voltage protection Diagnosis and Solution)

**Description:** Abnormal increases or decreases in voltage are detected by checking the specified voltage detection circuit.

### Recommended parts to prepare:

- Power supply wires
- IPM module board
- PCB
- Reactor

### Troubleshooting and repair:




## 6.9 PC04(Inverter compressor drive error Diagnosis and Solution)

**Description:** An abnormal inverter compressor drive is detected by a special detection circuit, including communication signal detection, voltage detection, compressor rotation speed signal detection and so on.

### Recommended parts to prepare:

- Connection wires
- IPM module board
- Outdoor fan assembly
- Compressor
- Outdoor PCB

### Troubleshooting and repair:



---


## 6.10 PC03(Pressure protection (low or high pressure) Diagnosis and Solution)


**Description:** Outdoor pressure switch cut off the system because high pressure is higher than 4.4 MPa or outdoor pressure switch cut off the system because low pressure is lower than 0.13 MPa, the LED displays the failure code.

**Recommended parts to prepare:**

- Connection wires
- Pressure switch
- Outdoor fan
- Outdoor main PCB
- Refrigerant

**Troubleshooting and repair:**






## 6.11 PC02(Compressor top (or IPM) temp. protection Diagnosis and Solution)


**Description:** For some models with overload protection, If the sampling voltage is not 5V, the LED will display the failure. If the temperature of IPM module is higher than a certain value, the LED displays the failure code.

### Recommended parts to prepare:

- Connection wires
- Outdoor PCB
- IPM module board
- High pressure protector
- System blockages

### Troubleshooting and repair:





## 6.12 PC0L (Low ambient temperature protection)

**Description:** It is a protection function. When compressor is off, outdoor ambient temperature(T4) is lower than -35°C. for 10s, the AC will stop and display the failure code.

When compressor is on, outdoor ambient temperature(T4) is lower than -40°C. for 10s, the AC will stop and display the failure code.

When outdoor ambient temperature(T4) is no lower than -32°C. for 10s, the unit will exit protection.


## 6.13 EH b3 (Communication malfunction between wire and master control) Diagnosis and Solution

**Description:** If Indoor PCB does not receive feedback from wired controller, the error displays on the wired controller

**Recommended parts to prepare:**

- Connection wires
- Indoor PCB
- Wired controller

**Troubleshooting and repair:**



---

## 6.14 EH bA(Communication error between the indoor unit and the external fan module)/ EH3A(External fan DC bus voltage is too low protection)/ EH3b(External fan DC bus voltage is too high fault) diagnosis and solution


**Description:** Indoor unit does not receive the feedback from external fan module during 150 seconds.

or Indoor unit receives abnormal increases or decreases in voltage from external fan module.

### Recommended parts to prepare:

- External drive board
- Indoor main PCB

### Troubleshooting and repair:



---


## 6.15 FHCC(Refrigerant sensor error) or EHC3(Refrigerant sensor is out of range) diagnosis and solution

**Description:** Indoor unit receives fault signal for 10s or indoor unit does not receive feedback from refrigerant sensor for 150s.

**Recommended parts to prepare:**

- Connection wires
- Sensors
- Indoor main PCB

**Troubleshooting and repair:**



## 6.16 EHC1(Refrigerant sensor detects leakage) or EHC2(Refrigerant sensor is out of range and leakage is detected) diagnosis and solution

### Description:


The refrigerant sensor detects a concentration higher than or equal to 10%\*LFL for 10 seconds or the refrigerant sensor detects a concentration higher than or equal to 20%\*LFL or the multi model receives the refrigerant leakage protection fault sent by the outdoor unit.

Multi-zone: Only the buzzer of the indoor unit that detects refrigerant leakage continues to sound the alarm, the shortest sound is 10 seconds, and the longest sound is 5 minutes (you can press any key such as remote control or wire control, APP and so on to eliminate the alarm), and the other non-refrigerant leakage fault indoor unit only displays "ECC1", but the buzzer does not sound.

### Recommended parts to prepare:

- Additional refrigerant

### Troubleshooting and repair:




## 6.17 EL11 (Communication malfunction between main unit and secondary units(for twins system) Diagnosis and Solution)

**Description:** When set in twins system, master unit and slave unit cannot be recognized normally.

**Recommended parts to prepare:**

- Connection wires
- Indoor PCB



## 6.18 EH12 (Main unit or secondary units malfunction(for twins system) ) Diagnosis and Solution)

**Description:** When set in twins system, one indoor unit displays this error code, which means another indoor unit is faulty. Check another indoor unit's error code and then follow the prescribed solutions to resolve the malfunction.


## 7. Check Procedures

### 7.1 Temperature Sensor Check

#### WARNING

Be sure to turn off all power supplies or disconnect all wires to avoid electric shock.  
Operate after compressor and coil have returned to normal temperature in case of injury.

1. Disconnect temperature sensor from PCB (Refer to Indoor Disassembly and Outdoor Disassembly).
2. Measure the resistance value of the sensor using a multi-meter.
3. Check corresponding temperature sensor resistance value table (Refer to Chapter 8. Appendix).



Note: The picture and the value are only for reference, actual condition and specific value may vary.

---

## Appendix

## Contents

- i) Temperature Sensor Resistance Value Table for TP (°C --K).....2
- ii) Other Temperature Sensors Resistance Value Table (°C – K) .....3
- iii) System Pressure Table .....4

## i) Temperature Sensor Resistance Value Table for TP (°C --K)

| °C  | °F | K Ohm | °C | °F  | K Ohm | °C | °F  | K Ohm | °C  | °F  | K Ohm |
|-----|----|-------|----|-----|-------|----|-----|-------|-----|-----|-------|
| °C  | °F | K Ohm | °C | °F  | K Ohm | °C | °F  | K Ohm | °C  | °F  | K Ohm |
| -20 | -4 | 542.7 | 20 | 68  | 68.66 | 60 | 140 | 13.59 | 100 | 212 | 3.702 |
| -19 | -2 | 511.9 | 21 | 70  | 65.62 | 61 | 142 | 13.11 | 101 | 214 | 3.595 |
| -18 | 0  | 483   | 22 | 72  | 62.73 | 62 | 144 | 12.65 | 102 | 216 | 3.492 |
| -17 | 1  | 455.9 | 23 | 73  | 59.98 | 63 | 145 | 12.21 | 103 | 217 | 3.392 |
| -16 | 3  | 430.5 | 24 | 75  | 57.37 | 64 | 147 | 11.79 | 104 | 219 | 3.296 |
| -15 | 5  | 406.7 | 25 | 77  | 54.89 | 65 | 149 | 11.38 | 105 | 221 | 3.203 |
| -14 | 7  | 384.3 | 26 | 79  | 52.53 | 66 | 151 | 10.99 | 106 | 223 | 3.113 |
| -13 | 9  | 363.3 | 27 | 81  | 50.28 | 67 | 153 | 10.61 | 107 | 225 | 3.025 |
| -12 | 10 | 343.6 | 28 | 82  | 48.14 | 68 | 154 | 10.25 | 108 | 226 | 2.941 |
| -11 | 12 | 325.1 | 29 | 84  | 46.11 | 69 | 156 | 9.902 | 109 | 228 | 2.86  |
| -10 | 14 | 307.7 | 30 | 86  | 44.17 | 70 | 158 | 9.569 | 110 | 230 | 2.781 |
| -9  | 16 | 291.3 | 31 | 88  | 42.33 | 71 | 160 | 9.248 | 111 | 232 | 2.704 |
| -8  | 18 | 275.9 | 32 | 90  | 40.57 | 72 | 162 | 8.94  | 112 | 234 | 2.63  |
| -7  | 19 | 261.4 | 33 | 91  | 38.89 | 73 | 163 | 8.643 | 113 | 235 | 2.559 |
| -6  | 21 | 247.8 | 34 | 93  | 37.3  | 74 | 165 | 8.358 | 114 | 237 | 2.489 |
| -5  | 23 | 234.9 | 35 | 95  | 35.78 | 75 | 167 | 8.084 | 115 | 239 | 2.422 |
| -4  | 25 | 222.8 | 36 | 97  | 34.32 | 76 | 169 | 7.82  | 116 | 241 | 2.357 |
| -3  | 27 | 211.4 | 37 | 99  | 32.94 | 77 | 171 | 7.566 | 117 | 243 | 2.294 |
| -2  | 28 | 200.7 | 38 | 100 | 31.62 | 78 | 172 | 7.321 | 118 | 244 | 2.233 |
| -1  | 30 | 190.5 | 39 | 102 | 30.36 | 79 | 174 | 7.086 | 119 | 246 | 2.174 |
| 0   | 32 | 180.9 | 40 | 104 | 29.15 | 80 | 176 | 6.859 | 120 | 248 | 2.117 |
| 1   | 34 | 171.9 | 41 | 106 | 28    | 81 | 178 | 6.641 | 121 | 250 | 2.061 |
| 2   | 36 | 163.3 | 42 | 108 | 26.9  | 82 | 180 | 6.43  | 122 | 252 | 2.007 |
| 3   | 37 | 155.2 | 43 | 109 | 25.86 | 83 | 181 | 6.228 | 123 | 253 | 1.955 |
| 4   | 39 | 147.6 | 44 | 111 | 24.85 | 84 | 183 | 6.033 | 124 | 255 | 1.905 |
| 5   | 41 | 140.4 | 45 | 113 | 23.89 | 85 | 185 | 5.844 | 125 | 257 | 1.856 |
| 6   | 43 | 133.5 | 46 | 115 | 22.89 | 86 | 187 | 5.663 | 126 | 259 | 1.808 |
| 7   | 45 | 127.1 | 47 | 117 | 22.1  | 87 | 189 | 5.488 | 127 | 261 | 1.762 |
| 8   | 46 | 121   | 48 | 118 | 21.26 | 88 | 190 | 5.32  | 128 | 262 | 1.717 |
| 9   | 48 | 115.2 | 49 | 120 | 20.46 | 89 | 192 | 5.157 | 129 | 264 | 1.674 |
| 10  | 50 | 109.8 | 50 | 122 | 19.69 | 90 | 194 | 5     | 130 | 266 | 1.632 |
| 11  | 52 | 104.6 | 51 | 124 | 18.96 | 91 | 196 | 4.849 |     |     |       |
| 12  | 54 | 99.69 | 52 | 126 | 18.26 | 92 | 198 | 4.703 |     |     |       |
| 13  | 55 | 95.05 | 53 | 127 | 17.58 | 93 | 199 | 4.562 |     |     |       |
| 14  | 57 | 90.66 | 54 | 129 | 16.94 | 94 | 201 | 4.426 |     |     |       |
| 15  | 59 | 86.49 | 55 | 131 | 16.32 | 95 | 203 | 4.294 |     |     |       |
| 16  | 61 | 82.54 | 56 | 133 | 15.73 | 96 | 205 | 4.167 |     |     |       |
| 17  | 63 | 78.79 | 57 | 135 | 15.16 | 97 | 207 | 4.045 |     |     |       |
| 18  | 64 | 75.24 | 58 | 136 | 14.62 | 98 | 208 | 3.927 |     |     |       |
| 19  | 66 | 71.86 | 59 | 138 | 14.09 | 99 | 210 | 3.812 |     |     |       |

## ii) Other Temperature Sensors Resistance Value Table (°C – K)

| °C  | °F | K Ohm   | °C | °F  | K Ohm   | °C | °F  | K Ohm   | °C  | °F  | K Ohm   |
|-----|----|---------|----|-----|---------|----|-----|---------|-----|-----|---------|
| -20 | -4 | 115.266 | 20 | 68  | 12.6431 | 60 | 140 | 2.35774 | 100 | 212 | 0.62973 |
| -19 | -2 | 108.146 | 21 | 70  | 12.0561 | 61 | 142 | 2.27249 | 101 | 214 | 0.61148 |
| -18 | 0  | 101.517 | 22 | 72  | 11.5    | 62 | 144 | 2.19073 | 102 | 216 | 0.59386 |
| -17 | 1  | 96.3423 | 23 | 73  | 10.9731 | 63 | 145 | 2.11241 | 103 | 217 | 0.57683 |
| -16 | 3  | 89.5865 | 24 | 75  | 10.4736 | 64 | 147 | 2.03732 | 104 | 219 | 0.56038 |
| -15 | 5  | 84.219  | 25 | 77  | 10      | 65 | 149 | 1.96532 | 105 | 221 | 0.54448 |
| -14 | 7  | 79.311  | 26 | 79  | 9.55074 | 66 | 151 | 1.89627 | 106 | 223 | 0.52912 |
| -13 | 9  | 74.536  | 27 | 81  | 9.12445 | 67 | 153 | 1.83003 | 107 | 225 | 0.51426 |
| -12 | 10 | 70.1698 | 28 | 82  | 8.71983 | 68 | 154 | 1.76647 | 108 | 226 | 0.49989 |
| -11 | 12 | 66.0898 | 29 | 84  | 8.33566 | 69 | 156 | 1.70547 | 109 | 228 | 0.486   |
| -10 | 14 | 62.2756 | 30 | 86  | 7.97078 | 70 | 158 | 1.64691 | 110 | 230 | 0.47256 |
| -9  | 16 | 58.7079 | 31 | 88  | 7.62411 | 71 | 160 | 1.59068 | 111 | 232 | 0.45957 |
| -8  | 18 | 56.3694 | 32 | 90  | 7.29464 | 72 | 162 | 1.53668 | 112 | 234 | 0.44699 |
| -7  | 19 | 52.2438 | 33 | 91  | 6.98142 | 73 | 163 | 1.48481 | 113 | 235 | 0.43482 |
| -6  | 21 | 49.3161 | 34 | 93  | 6.68355 | 74 | 165 | 1.43498 | 114 | 237 | 0.42304 |
| -5  | 23 | 46.5725 | 35 | 95  | 6.40021 | 75 | 167 | 1.38703 | 115 | 239 | 0.41164 |
| -4  | 25 | 44      | 36 | 97  | 6.13059 | 76 | 169 | 1.34105 | 116 | 241 | 0.4006  |
| -3  | 27 | 41.5878 | 37 | 99  | 5.87359 | 77 | 171 | 1.29078 | 117 | 243 | 0.38991 |
| -2  | 28 | 39.8239 | 38 | 100 | 5.62961 | 78 | 172 | 1.25423 | 118 | 244 | 0.37956 |
| -1  | 30 | 37.1988 | 39 | 102 | 5.39689 | 79 | 174 | 1.2133  | 119 | 246 | 0.36954 |
| 0   | 32 | 35.2024 | 40 | 104 | 5.17519 | 80 | 176 | 1.17393 | 120 | 248 | 0.35982 |
| 1   | 34 | 33.3269 | 41 | 106 | 4.96392 | 81 | 178 | 1.13604 | 121 | 250 | 0.35042 |
| 2   | 36 | 31.5635 | 42 | 108 | 4.76253 | 82 | 180 | 1.09958 | 122 | 252 | 0.3413  |
| 3   | 37 | 29.9058 | 43 | 109 | 4.5705  | 83 | 181 | 1.06448 | 123 | 253 | 0.33246 |
| 4   | 39 | 28.3459 | 44 | 111 | 4.38736 | 84 | 183 | 1.03069 | 124 | 255 | 0.3239  |
| 5   | 41 | 26.8778 | 45 | 113 | 4.21263 | 85 | 185 | 0.99815 | 125 | 257 | 0.31559 |
| 6   | 43 | 25.4954 | 46 | 115 | 4.04589 | 86 | 187 | 0.96681 | 126 | 259 | 0.30754 |
| 7   | 45 | 24.1932 | 47 | 117 | 3.88673 | 87 | 189 | 0.93662 | 127 | 261 | 0.29974 |
| 8   | 46 | 22.5662 | 48 | 118 | 3.73476 | 88 | 190 | 0.90753 | 128 | 262 | 0.29216 |
| 9   | 48 | 21.8094 | 49 | 120 | 3.58962 | 89 | 192 | 0.8795  | 129 | 264 | 0.28482 |
| 10  | 50 | 20.7184 | 50 | 122 | 3.45097 | 90 | 194 | 0.85248 | 130 | 266 | 0.2777  |
| 11  | 52 | 19.6891 | 51 | 124 | 3.31847 | 91 | 196 | 0.82643 | 131 | 268 | 0.27078 |
| 12  | 54 | 18.7177 | 52 | 126 | 3.19183 | 92 | 198 | 0.80132 | 132 | 270 | 0.26408 |
| 13  | 55 | 17.8005 | 53 | 127 | 3.07075 | 93 | 199 | 0.77709 | 133 | 271 | 0.25757 |
| 14  | 57 | 16.9341 | 54 | 129 | 2.95896 | 94 | 201 | 0.75373 | 134 | 273 | 0.25125 |
| 15  | 59 | 16.1156 | 55 | 131 | 2.84421 | 95 | 203 | 0.73119 | 135 | 275 | 0.24512 |
| 16  | 61 | 15.3418 | 56 | 133 | 2.73823 | 96 | 205 | 0.70944 | 136 | 277 | 0.23916 |
| 17  | 63 | 14.6181 | 57 | 135 | 2.63682 | 97 | 207 | 0.68844 | 137 | 279 | 0.23338 |
| 18  | 64 | 13.918  | 58 | 136 | 2.53973 | 98 | 208 | 0.66818 | 138 | 280 | 0.22776 |
| 19  | 66 | 13.2631 | 59 | 138 | 2.44677 | 99 | 210 | 0.64862 | 139 | 282 | 0.22231 |

### iii) System Pressure Table-R454B

| Pressure |      |       | Temperature |       | Pressure |       |        | Temperature |       |
|----------|------|-------|-------------|-------|----------|-------|--------|-------------|-------|
| Kpa      | bar  | PSI   | °C          | °F    | Kpa      | bar   | PSI    | °C          | °F    |
| 58.196   | 0.58 | 8.44  | -60         | -76   | 935.23   | 9.35  | 135.64 | 8           | 46.4  |
| 61.517   | 0.62 | 8.92  | -59         | -74.2 | 963.75   | 9.64  | 139.78 | 9           | 48.2  |
| 64.988   | 0.65 | 9.43  | -58         | -72.4 | 992.93   | 9.93  | 144.01 | 10          | 50    |
| 68.615   | 0.69 | 9.95  | -57         | -70.6 | 1022.8   | 10.23 | 148.34 | 11          | 51.8  |
| 72.402   | 0.72 | 10.50 | -56         | -68.8 | 1053.3   | 10.53 | 152.76 | 12          | 53.6  |
| 76.354   | 0.76 | 11.07 | -55         | -67   | 1084.5   | 10.85 | 157.29 | 13          | 55.4  |
| 80.478   | 0.80 | 11.67 | -54         | -65.2 | 1116.4   | 11.16 | 161.91 | 14          | 57.2  |
| 84.776   | 0.85 | 12.30 | -53         | -63.4 | 1149     | 11.49 | 166.64 | 15          | 59    |
| 89.256   | 0.89 | 12.95 | -52         | -61.6 | 1182.3   | 11.82 | 171.47 | 16          | 60.8  |
| 93.923   | 0.94 | 13.62 | -51         | -59.8 | 1216.3   | 12.16 | 176.40 | 17          | 62.6  |
| 98.781   | 0.99 | 14.33 | -50         | -58   | 1251.1   | 12.51 | 181.45 | 18          | 64.4  |
| 103.84   | 1.04 | 15.06 | -49         | -56.2 | 1286.6   | 12.87 | 186.60 | 19          | 66.2  |
| 109.1    | 1.09 | 15.82 | -48         | -54.4 | 1322.8   | 13.23 | 191.85 | 20          | 68    |
| 114.56   | 1.15 | 16.61 | -47         | -52.6 | 1359.9   | 13.60 | 197.23 | 21          | 69.8  |
| 120.25   | 1.20 | 17.44 | -46         | -50.8 | 1397.7   | 13.98 | 202.71 | 22          | 71.6  |
| 126.15   | 1.26 | 18.30 | -45         | -49   | 1436.3   | 14.36 | 208.31 | 23          | 73.4  |
| 132.28   | 1.32 | 19.18 | -44         | -47.2 | 1475.7   | 14.76 | 214.02 | 24          | 75.2  |
| 138.64   | 1.39 | 20.11 | -43         | -45.4 | 1515.9   | 15.16 | 219.85 | 25          | 77    |
| 145.24   | 1.45 | 21.06 | -42         | -43.6 | 1557     | 15.57 | 225.82 | 26          | 78.8  |
| 152.09   | 1.52 | 22.06 | -41         | -41.8 | 1598.9   | 15.99 | 231.89 | 27          | 80.6  |
| 159.18   | 1.59 | 23.09 | -40         | -40   | 1641.6   | 16.42 | 238.09 | 28          | 82.4  |
| 166.54   | 1.67 | 24.15 | -39         | -38.2 | 1685.2   | 16.85 | 244.41 | 29          | 84.2  |
| 174.15   | 1.74 | 25.26 | -38         | -36.4 | 1729.7   | 17.30 | 250.86 | 30          | 86    |
| 182.04   | 1.82 | 26.40 | -37         | -34.6 | 1775     | 17.75 | 257.43 | 31          | 87.8  |
| 190.2    | 1.90 | 27.59 | -36         | -32.8 | 1821.3   | 18.21 | 264.15 | 32          | 89.6  |
| 198.65   | 1.99 | 28.81 | -35         | -31   | 1868.4   | 18.68 | 270.98 | 33          | 91.4  |
| 207.39   | 2.07 | 30.08 | -34         | -29.2 | 1916.5   | 19.17 | 277.95 | 34          | 93.2  |
| 216.42   | 2.16 | 31.39 | -33         | -27.4 | 1965.6   | 19.66 | 285.08 | 35          | 95    |
| 225.76   | 2.26 | 32.74 | -32         | -25.6 | 2015.5   | 20.16 | 292.31 | 36          | 96.8  |
| 235.41   | 2.35 | 34.14 | -31         | -23.8 | 2066.5   | 20.67 | 299.71 | 37          | 98.6  |
| 245.37   | 2.45 | 35.59 | -30         | -22   | 2118.4   | 21.18 | 307.24 | 38          | 100.4 |
| 255.67   | 2.56 | 37.08 | -29         | -20.2 | 2171.3   | 21.71 | 314.91 | 39          | 102.2 |
| 266.29   | 2.66 | 38.62 | -28         | -18.4 | 2225.2   | 22.25 | 322.73 | 40          | 104   |
| 277.25   | 2.77 | 40.21 | -27         | -16.6 | 2280.2   | 22.80 | 330.70 | 41          | 105.8 |
| 288.56   | 2.89 | 41.85 | -26         | -14.8 | 2336.1   | 23.36 | 338.81 | 42          | 107.6 |
| 300.22   | 3.00 | 43.54 | -25         | -13   | 2393.2   | 23.93 | 347.09 | 43          | 109.4 |
| 312.24   | 3.12 | 45.28 | -24         | -11.2 | 2451.3   | 24.51 | 355.52 | 44          | 111.2 |
| 324.63   | 3.25 | 47.08 | -23         | -9.4  | 2510.4   | 25.10 | 364.09 | 45          | 113   |
| 337.39   | 3.37 | 48.93 | -22         | -7.6  | 2570.7   | 25.71 | 372.84 | 46          | 114.8 |
| 350.54   | 3.51 | 50.84 | -21         | -5.8  | 2632.1   | 26.32 | 381.74 | 47          | 116.6 |
| 364.08   | 3.64 | 52.80 | -20         | -4    | 2694.7   | 26.95 | 390.82 | 48          | 118.4 |
| 378.02   | 3.78 | 54.83 | -19         | -2.2  | 2758.3   | 27.58 | 400.04 | 49          | 120.2 |
| 392.37   | 3.92 | 56.91 | -18         | -0.4  | 2823.2   | 28.23 | 409.46 | 50          | 122   |
| 407.13   | 4.07 | 59.05 | -17         | 1.4   | 2889.3   | 28.89 | 419.04 | 51          | 123.8 |

---

|        |      |        |     |      |        |       |        |    |       |
|--------|------|--------|-----|------|--------|-------|--------|----|-------|
| 422.31 | 4.22 | 61.25  | -16 | 3.2  | 2956.5 | 29.57 | 428.79 | 52 | 125.6 |
| 437.92 | 4.38 | 63.51  | -15 | 5    | 3025   | 30.25 | 438.72 | 53 | 127.4 |
| 453.98 | 4.54 | 65.84  | -14 | 6.8  | 3094.7 | 30.95 | 448.83 | 54 | 129.2 |
| 470.47 | 4.70 | 68.23  | -13 | 8.6  | 3165.7 | 31.66 | 459.13 | 55 | 131   |
| 487.43 | 4.87 | 70.69  | -12 | 10.4 | 3238.1 | 32.38 | 469.63 | 56 | 132.8 |
| 504.84 | 5.05 | 73.22  | -11 | 12.2 | 3311.7 | 33.12 | 480.30 | 57 | 134.6 |
| 522.73 | 5.23 | 75.81  | -10 | 14   | 3386.7 | 33.87 | 491.18 | 58 | 136.4 |
| 541.1  | 5.41 | 78.48  | -9  | 15.8 | 3463   | 34.63 | 502.25 | 59 | 138.2 |
| 559.95 | 5.60 | 81.21  | -8  | 17.6 | 3540.7 | 35.41 | 513.52 | 60 | 140   |
| 579.31 | 5.79 | 84.02  | -7  | 19.4 | 3619.9 | 36.20 | 525.00 | 61 | 141.8 |
| 599.16 | 5.99 | 86.90  | -6  | 21.2 | 3700.5 | 37.01 | 536.69 | 62 | 143.6 |
| 619.54 | 6.20 | 89.85  | -5  | 23   | 3782.7 | 37.83 | 548.61 | 63 | 145.4 |
| 640.43 | 6.40 | 92.88  | -4  | 24.8 | 3866.3 | 38.66 | 560.74 | 64 | 147.2 |
| 661.86 | 6.62 | 95.99  | -3  | 26.6 | 3951.5 | 39.52 | 573.10 | 65 | 149   |
| 683.82 | 6.84 | 99.18  | -2  | 28.4 | 4038.3 | 40.38 | 585.69 | 66 | 150.8 |
| 706.34 | 7.06 | 102.44 | -1  | 30.2 | 4126.8 | 41.27 | 598.52 | 67 | 152.6 |
| 729.41 | 7.29 | 105.79 | 0   | 32   | 4217   | 42.17 | 611.60 | 68 | 154.4 |
| 753.06 | 7.53 | 109.22 | 1   | 33.8 | 4309   | 43.09 | 624.95 | 69 | 156.2 |
| 777.28 | 7.77 | 112.73 | 2   | 35.6 | 4402.9 | 44.03 | 638.56 | 70 | 158   |
| 802.08 | 8.02 | 116.33 | 3   | 37.4 | 4498.7 | 44.99 | 652.46 | 71 | 159.8 |
| 827.48 | 8.27 | 120.01 | 4   | 39.2 | 4596.5 | 45.97 | 666.64 | 72 | 161.6 |
| 853.49 | 8.53 | 123.78 | 5   | 41   | 4696.5 | 46.97 | 681.15 | 73 | 163.4 |
| 880.11 | 8.80 | 127.64 | 6   | 42.8 | 4798.9 | 47.99 | 696.00 | 74 | 165.2 |
| 907.35 | 9.07 | 131.60 | 7   | 44.6 | 4904.1 | 49.04 | 711.25 | 75 | 167   |